Anritsu

MG0301C

π/4 DQPSK Modulation Unit

Operation Manual

RETURN THIS MANUAL

IF NOT RETURNED,
YOU WILL BE CHARGED
A MINIMUM OF $50.00

PLEASE RETURN TO:
AT&T CAPITAL CORPORATION
INSTRUMENT & DATA SERVICES
1830 WEST AIRFIELD DRIVE
DFW AIRPORT, TX 75261

14004-9 23 March 95

Read this manual before using the equipment.
Keep this manual with the equipment.



MG0301C

π/4 DQPSK Modulation Unit

Operation Manual

Third Edition

Read this manual after reading the Digital Modulation Signal Generator operation manual first. Keep it handy so that it can be read when necessary.

Measuring Instruments Division
Measurement Group

ANRITSU CORPORATION

MAR.
1996

Document: M-W0872AE-3.0

Safety Symbols

To prevent the risk of personal injury or loss related to equipment malfunction, Anritsu Corporation uses the following safety symbols to indicate safety-related information. Insure that you clearly understand the meanings of the symbols BEFORE using the equipment.

Symbols used in manual

WARNING	This indicates a hazardous procedure that could result in serious injury or death if not performed properly.
CAUTION	This indicates a hazardous procedure or danger that could result in light-to-severe injury, or loss related to equipment malfunction, if proper precautions are not taken.

MG0301C π/4 DQPSK Modulation Unit
Operation Manual

August 1994 (First Edition)
December 1995 (Third Edition)

Copyright © 1994−1995 by Anritsu Corporation

All rights reserved. No part of this manual may be reproduced without the prior written permission of Anritsu Corporation.

The contents of this manual may be changed without prior notice.

Printed in japan

Equipment Certificate

Anritsu Corporation certifies that this equipment was tested before shipment using calibrated measuring instruments with direct traceability to public testing organizations recognized by national research laboratories including the Electrotechnical Laboratory, the National Research Laboratory and the Communication Research laboratory, and was found to meet the published specifications.

Anritsu Warranty

Anritsu Corporation will repair this equipment free-of-charge if a malfunction occurs within 1 year after shipment due to a manufacturing fault, provided that this warranty is rendered void under any or all of the following conditions.

- The fault is outside the scope of the warranty conditions described in the operation manual.
- The fault is due to misoperation, misuse, or unauthorized modification or repair of the equipment by the customer.
- The fault is due to severe usage clearly exceeding normal usage.
- The fault is due to improper or insufficient maintenance by the customer.
- The fault is due to natural disaster including fire, flooding and earthquake, etc.
- The fault is due to use of non-specified peripheral equipment, peripheral parts, consumables, etc.
- The fault is due to use of a non-specified power supply or in a non-specified installation location.

In addition, this warranty is valid only for the original equipment purchaser. It is not transferable if the equipment is resold.

Anritsu Corporation will not accept liability for equipment faults due to unforeseen and unusual circumstances, nor for faults due to mishandling by the customer.

Anritsu Corporation Contact

If this equipment develops a fault, contact Anritsu Corporation or its representatives at the address in this manual.

CE Marking

Anritsu affix the CE Conformity Marking on the following product (s) accordance with the Council Directive 93/68/EEC to indicate that they conform with the EMC directive of the European Union (EU).

CE Conformity Marking

CE

1. Product Name/Model Name

Product Name: Digital Modulation Signal Generator, and Expansion Unit

Model Name: MG3670B, MG3671A, MG3660A, and MG03××□

2. Applied Directive

EMC: Council Directive 89/336/EEC

3. Applied Standards

Electromagnetic radiation:

EN55011 (ISM, Group 1, Class A equipment)

Immunity:

EN50082-1

		Performance Criteria*
IEC801-2 (ESD)	4 kVCD, 8 kVAD	B
IEC801-3 (Rad.)	3 V/m	A
IEC801-4 (EFT)	1 kV	B

*: Performance Criteria

A: No performance degradation or function loss

B: Self-recovered temporary degradation of performance or temporary loss of function

ABOUT THIS MANUAL

(1) Composition of MG0301C Operation Manuals

The operation manual of the MG0301C (π/4 DQPSK Modulation Unit) is composed of the following two parts. The related operations of the MG0303B (Burst Function Unit) are also explained. The term "MG3670 series" mentioned in this operation manual refers to both the MG3670B and the MG3671A. Substitute either name for the term as appropriate. Since operation manuals for the MG3670 series and the MG3660A are available as separate volumes, read them together with this manual.



Panel Operating Instructions part: Provides information on the MG0301C outline, preparation before use, manual (local) operation, measuremant, performance test, storage, transportation, screen transition, communication system, and error message.

GPIB remote control part: Provides information on the MG0301C remote control which conforms with IEEE488.2 standards. To assist creating GPIB programs, this part gives examples of N88 BASIC language programs that run on the NEC Corp. PC9800 series of personal computers.

(2) The relations between the installed units and the expanded functions

The MG0301C (π/4 DQPSK Modulation Unit) and the MG0303B (Burst Function Unit) are expansion units, and are inserted in the MG3670 series • MG3660A Digital Modulation Signal Generator.

The relations between the installed units and the expanded functions are explained below:

Units installed	Modulation system	Modulation pattern	RF output
MG0301C only	π/4 DQPSK Modulation ● Bit rate: 42 kbps, Filter: $\alpha=0.5$ ● Bit rate: 48.6 kbps, Filter: $\alpha=0.35$ ● Bit rate: 384 kbps, Filter: $\alpha=0.5$ ● Bit rate: 44.2kbps, Filter: $\alpha=0.4$	● PN9/PN15-stage pseudorandom pattern ● Free 4-bit repetition pattern	● Continuous wave
MG0301C + MG0303B	π/4 DQPSK Modulation ● Bit rate: 42 kbps, Filter: $\alpha=0.5$ ● Bit rate: 48.6 kbps, Filter: $\alpha=0.35$ ● Bit rate: 384 kbps, Filter: $\alpha=0.5$ ● Bit rate: 44.2kbps, Filter: $\alpha=0.4$	● PN9/PN15-stage pseudorandom pattern ● Free 4-bit repetitionpattern ● Pattern conforming to the systems	● Continuous wave ● Burst wave

(Blank)

MG0301C

π/4 DQPSK Modulation Unit

Operation Manual
(Panel Operating Instructions)

(Blank)

TABLE OF CONTENTS

SECTION 1 GENERAL 1-1

1.1 Product Outline 1-3

1.2 Composition of Operation Manual 1-4

1.3 Equipment Configuration 1-5
1.3.1 Standard configuration 1-5
1.3.2 Unit 1-5

1.4 Specifications 1-6
1.4.1 MG0301C π/4 DQPSK Modulation Unit specifications 1-6
1.4.2 MG0303B Burst Function Unit specifications 1-7

SECTION 2 BASIC OPERATION 2-1

2.1 Screen Transition 2-3

2.2 Setting the Modulation Parameters 2-4

2.3 Setting Internal Modulation Data 2-7

2.4 Internal Modulation Data Memory 2-9
2.4.1 Saving internal modulation data 2-9
2.4.2 Recalling internal modulation data 2-13
2.4.3 Deleting internal modulation data 2-14
2.4.4 Listing internal modulation data 2-16

2.5 I, Q Signal Outputs 2-17

2.6 Auxiliary signal outputs 2-19
2.6.1 Data, data clock and symbol clock signals 2-19
2.6.2 Pattern sync signal 2-19
2.6.3 Burst gate signal 2-22

2.7 Auxiliary Inputs Signal 2-24
2.7.1 Data, data clock and symbol clock signals 2-24
2.7.2 Burst gate signal 2-24

2.8 Symbol Adjust Function 2-25

2.9 Phase Encode Function 2-26

SECTION 3 DETAILED OPERATIONS 3-1

3.1 Operating the PDC System 3-3
3.1.1 Frame composition 3-3
3.1.2 Slot composition 3-3
3.1.3 Standard internal modulation data 3-6

3.2 Operating the PHP System 3-8
3.2.1 Frame composition 3-8
3.2.2 Slot composition 3-8
3.2.3 Standard internal modulation data 3-12

3.3 Operating the NADC System 3-15
3.3.1 Frame composition 3-15
3.3.2 Slot composition 3-15
3.3.3 Standard internal modulation data 3-16

3.4 Operating the TFTS System 3-18
3.4.1 Frame composition 3-18
3.4.2 Slot composition 3-18
3.4.3 Standard internal modulation data 3-20

3.5 Operating the PDC_H System 3-22
3.5.1 Frame composition 3-22
3.5.2 Slot composition 3-22
3.5.3 Standard internal modulation data 3-26

3.6 Detailed Trigger Function 3-28
3.6.1 Operation of the internal trigger 3-28
3.6.2 Operation of the external trigger 3-28
3.6.3 Output Timing of Burst Trigger and RF Signals 3-30
3.6.4 Relationships Between RF Signal and Symbol Judgment Point 3-33

SECTION 4 MEASUREMENT 4-1

4.1 Code Error Rate Measurement for Receiver 4-3

4.2 Demodulator Evaluation Measurement 4-5

4.3 Modulator Evaluation Measurement 4-6

SECTION 5 PERFORMANCE TESTS 5-1

5.1 Performance Tests Requirement 5-3

5.2 Instruments Required for Performance Tests 5-3

5.3 Performance Tests 5-4

5.3.1 I/Q signal modulation accuracy 5-4

5.3.2 RF output modulation accuracy 5-6

5.3.3 Modulation pattern 5-8

5.3.4 Burst signal On/Off ratio 5-10

5.3.5 Leakage power of adjacent channel characteristics 5-11

SECTION 6 STORAGE AND TRANSPORTATION 6-1

6.1 Storage Precautions 6-3

6.1.1 Precautions before storage 6-3

6.1.2 Recommended storage precautions 6-3

6.2 Repacking and Transportation 6-3

6.2.1 Repacking 6-3

6.2.2 Transportation 6-3

(Blank)

SECTION 1
GENERAL

This section outlines the MG0301C π / 4 DQPSK Modulation Unit and explains the composition of this manual, the configuration of the MG0301C the standard accessories, with the related unit for expanding the MG0301C capabilities, and the MG0301C and MG0303B specifications.

TABLE OF CONTENTS

1.1 Product Outline 1-3

1.2 Composition of Operation Manual 1-4

1.3 Equipment Configuration 1-5
- 1.3.1 Standard configuration 1-5
- 1.3.2 Unit 1-5

1.4 Specifications 1-6
- 1.4.1 MG0301C π/4 DQPSK Modulation Unit specifications 1-6
- 1.4.2 MG0303B Burst Function Unit specifications 1-7

(Blank)

SECTION 1
GENERAL

1.1 Product Outline

The MG0301C $\pi/4$ DQPSK Modulation Unit and the MG0303B Burst Function Unit are expansion units, and are installed in the MG3670 series • MG3660A Digital Modulation Signal Generator to generate the I/Q signals for $\pi/4$ DQPSK modulation.

Installing the MG0301C to the MG3670 series • MG3660A permits modulation signal output conforming to communication systems including Japan's digital cordless telephones (PHP: Personal Handy Phone), Japan's mobile telephones (PDC: Personal Digital Cellular), North-American mobile telephones (NADC: North-American Digital Cellular Systems) and terrestrial flight telephone services (TFTS).

Installing the MG0301C and the MG0303B enables outputting the burst signal based on each the communication-system channel format.

The table lists the model names of digital modulation signal generators (main instruments) capable of housing the MG0301C $\pi/4$ DQPSK Modulation Unit and the MG0303B Burst Function Unit.

Model	Name	Remarks
MG3670B	Digital Modulation Signal Generator	MG3670 series
MG3671A	Digital Modulation Signal Generator	MG3670 series
MG3660A	Digital Modulation Signal Generator	
MG3670A†	Digital Modulation Signal Generator	Requires maintenance

† In order to combine the expansion units with the MG3670A, the MG3670A must be remodeled. Please contact your nearest Anritsu representative.

1.2 Composition of Operation Manual

This operation manual is composed of six sections. Each section is outlined below.

Section composition	Explanation
SECTION 1 GENERAL	Provides information about product outline, composition of manual, equipment configuration with standard accessories, related unit, and specifications
SECTION 2 BASIC OPERATION	Provides information about basic operation and auxiliary control signals
SECTION 3 DETAILED OPERATIONS	Provides information about operating communication systems and trigger function
SECTION 4 MEASUREMENT	Provides information about typical measurement examples for the digital mobile radio.
SECTION 5 PERFORMANCE TESTS	Provides information about equipment required for executing MG0301C performance tests, setup, and procedure of performance tests
SECTION 6 STORAGE AND TRANSPORTATION	Provides information about regular care and long-term storage as well as repacking and transportation

1.3 Equipment Configuration

This paragraph describes the configuration of the MG0301C π/4 DQPSK Modulation Unit and the related unit to expand the function.

1.3.1 Standard configuration

The table below shows the configuration of the MG0301C with the standard accessories:

Table 1-1 Standard Composition

Item	Model / Order No.	Name	Qty.	Remarks
Main instrument	MG0301C	π/4 DQPSK Modulation Unit	1	
Accessories	W0872AE	Operation manual	1	Involves the description of the MG0303B function related to the MG0301C

1.3.2 Unit

The table below shows the related units for the MG3670 series • MG3660A. (The MG0301C not included)

Table 1-2 Expansion Units

Modulation Units for Communication Systems:

Model No.	Name	System to be used
MG0302A	GMSK Modulation Unit	GSM, PCN, CT2
MG0305A	GFSK Modulation Unit	DECT
MG0307A	π/4 DQPSK Modulation Unit	PACS, WCPE, PHP

Burst Function Unit: used with the modulation units for Communication Systems

Model No.	Name	System to be used
MG0303B	Burst Function Unit	PDC[†1], PHP, NADC, TFTS, PDC_H[†2], CT2, GSM, PCN, DECT, PACS, WCPE

[†1] The full rate of Japanese Personal Digital Cellular system is expressed as PDC.

[†2] The half rate of Japanese Personal Digital Cellular system is expressed as PDC_H.

1.4 Specifications

The MG0301C and MG0303B specifications are listed in the following table.

1.4.1 MG0301C π/4 DQPSK Modulation Unit specifications

The MG0301C π/4 DQPSK Modulation Unit specifications are listed in Table 1-3.

Table 1-3 MG0301C π/4 DQPSK Modulation Unit Specifications

Applicable system	PDC, PHP, NADC, TFTS, PDC_H
Modulation system	π / 4 DQPSK
Vector error	I/Q signal: ≦1.5% rms (at 50 Ω output) RF signal: ≦1.8% rms (MG3670B/3671A, at ≦ +5 dBm output) ≦2.5% rms (MG3660A, at +5 dBm output)
Internal modulation data	Pseudorandom pattern: PN15/PN9 [Free 4-bit repetition pattern (ex: 1010, 1111)]
External modulation data	Data Clock: Covering ±5% of bit rate Data: Digital data synchronized with Data Clock Symbol Clock: Clock specified by Data synchronized with Data Clock [TTL level, BNC connector, polarity selectable]
I/Q signal output	Selectable 50 Ω or CMOS (600 Ω), BNC connector 50 Ω setting: 1 Vp-p ±2% (modulation data: 0000) CMOS setting: Variable in 10% steps over the 10% to 100% range of 1 Vp-p ±2% (modulation data: 0000) Variable offset voltage: 0 to 4 V (1 mV steps)
Adjacent channel leakage power ratio	For PHP system ≦ −74 dB: MG3670B/3671A, 600 kHz/900 kHz offset, ±96 kHz bandwidth, ≧10 MHz ≦ −69 dB: MG3660A, 600 kHz/900 kHz offset, ±96 kHz bandwidth, ≧10 MHz
PDC	Carrier frequency range: 300 kHz to 2250 MHz† Bit rate: 42 kbps Baseband filter: Root Nyquist: $\alpha=0.5$, Nyquist: $\alpha=0.5$
PHP	Carrier frequency range: 1 to 2250 MHz† Bit rate: 384 kbps Baseband filter: Root Nyquist: $\alpha=0.5$, Nyquist: $\alpha=0.5$
NADC	Carrier frequency range: 300 kHz to 2250 MHz† Bit rate: 48.6 kbps Baseband filter: Root Nyquist: $\alpha=0.35$, Nyquist: $\alpha=0.35$
TFTS	Carrier frequency range: 300 kHz to 2250 MHz† Bit rate: 44.2 kHz Baseband filter: Root Nyquist: $\alpha=0.4$, Nyquist: $\alpha=0.4$
PDC_H	Carrier frequency range: 300 kHz to 2250 MHz† Bit rate: 44.2 kHz Baseband filter: Root Nyquist: $\alpha=0.5$, Nyquist: $\alpha=0.5$

† The upper limit of carrier frequency conforms to the specification of the MG3670 series • MG3660A.

1.4.2 MG0303B Burst Function Unit specifications

Table 1-4 lists the MG0303B Burst Function Unit specifications for (PDC / PHP / NADC / TFTS / PDC__H) when used with the MG0301C.

Table 1-4 MG0303B Burst Function Unit Specifications (1/2)

Applicable communication system		PDC, PHP, NADC, TFTS, PDC__H (with MG0301C)
Modulation signal	Internal data mode	TDMA framing specified for each system; modulation in each time slot using any Internal data mode
	Internal modulation data	Pseudorandom pattern: PN15/PN9†(for device) Specified pattern based on communication channel format specified for each system: Up/down communication channel, VOX control TCH section consists of pseudorandom pattern (PN15/PN9)†
	External data mode	Data Clock: Covering ±5% of bit rate Data: Digital data synchronized with Data Clock Symbol Clock: Clock specified by Data synchronized with Data Clock [TTL level, BNC connector, polarity selectable]
Auxiliary signal input	Burst trigger input	Outputs burst wave synchronized with trigger input signal of burst repetition. Input period: burst repetition rate ±1 symbol [TTL level, BNC connector (rear panel), polarity selectable]
	Burst gate input	Outputs burst waveform corresponding to input signal width. Input signal width: ≧14 symbols, period: ≧22 symbols [TTL level, BNC connector (rear panel), polarity selectable]
Auxiliary signal output	Burst trigger output	Outputs 1-symbol width pulse at same cycle as burst waveform output. [TTL level, BNC connector (rear panel), polarity selectable]
	Pattern sync output	Following outputs selectable at internal modulation: PN Clock: Data clock corresponding to pseudorandom pattern part PN Gate: Gate signal corresponding to pseudorandom pattern part RF Gate: Signal for controlling pulse modulator in accordance with burst signal output [TTL level, BNC connector (rear panel)]
	Burst gate output	Outputs gate signal corresponding to burst waveform output at internal modulation. [TTL level, BNC connector (rear panel), polarity selectable]
RF output	Burst on/off ratio	≧80 dB (MG3670B/3671A, +5 dBm output, PDC, NADC, TFTS, PDC__H), ≧75 dB (MG3660A, +5 dBm output, PDC, NADC, TFTS, PDC__H) ≧75 dB (+5 dBm output, PHP)
	Rise/fall time	Equivalent to 2 symbols

† Pseudorandom pattern in each has different phase, and its pattern within the TCH segment of slots is continuous.

Table 1-4 MG0303B Burst Function Unit Specifications (2/2)

Memory	Pattern memory	100 patterns (store and recall of internal modulation pattern data)
PDC	Burst repetition period	20 ms
	Slot configuration	For device, up/down communication channel, up VOX control
	Output slot select	On/off selectable for any slots of Slot 0 to Slot 2 (excluding all slots off)
	Edit function	SW/CC/SACCH: Any data, TCH: PN9/PN15† selectable
	Scramble function	TCH + SF + SACCH scramble on/off, any scramble code setting
PHP	Burst repetition period	5 ms
	Slot configuration	For device, up/down communication channel, VOX control
	Output slot select	On/off selectable for any slots of Slot 0 to Slot 2 (excluding all slots off)
	Edit function	SYNC/SACCH/CDVCC: Any data, DATA: PN9/PN15† selectable
	Scramble function	TCH + CRC, scramble and secret scramble on/off, any scramble code setting
	Adjacent channel leakage power ratio	≦ −74 dB: MG3670B/3671A, 600 kHz/900 kHz offset, ±96 kHz bandwidth, ≧10 MHz ≦ −69 dB: MG3660A, 600 kHz/900 kHz offset, ±96 kHz bandwidth, ≧10 MHz
NADC	Burst repetition period	20 ms
	Slot configuration	For device, up/down communication channel
	Output slot select	On/off selectable for any slots of Slot 0 to Slot 2 (excluding all slots off)
	Edit function	SYNC/SACCH/CDVCC: Any data, DATA: PN9/PN15† selectable
TFTS	Burst repetition period	80 ms
	Slot configuration	For device, up/down communication channel
	Output slot select	On/off selectable for any slots of Slot 0 to Slot 15 (excluding all slots off)
	Edit function	S: Any data, DATA: PN9/PN15† selectable
PDC_H	Burst repetition period	40 ms
	Slot configuration	For device, up/down communication channel, up VOX control
	Output slot select	On/off selectable for any slots of Slot 0 to Slot 5 (excluding all slots off)
	Edit function	SW/CC/SACCH: Any data, TCH: PN9/PN15† selectable
	Scramble function	TCH + SF + SACCH scramble on/off, any scramble code setting

† Pseudorandom pattern in each has different phase, and its pattern within the TCH segment of slots is continuous.

SECTION 2
BASIC OPERATION

This section describes basic operation procedures for the MG0301C π/4 DQPSK Modulation Unit and the MG0303B Burst Function Unit and their auxiliary signals. See Section 3 on how to use the modulation patterns and trigger signals for each system.

TABLE OF CONTENTS

2.1 Screen Transition 2-3

2.2 Setting the Modulation Parameters 2-4

2.3 Setting Internal Modulation Data 2-7

2.4 Internal Modulation Data Memory 2-9
- 2.4.1 Saving internal modulation data 2-9
- 2.4.2 Recalling internal modulation data 2-13
- 2.4.3 Deleting internal modulation data 2-14
- 2.4.4 Listing internal modulation data 2-16

2.5 I, Q Signal Outputs 2-17

2.6 Auxiliary signal outputs 2-19
- 2.6.1 Data, data clock and symbol clock signals 2-19
- 2.6.2 Pattern sync signal 2-19
- 2.6.3 Burst gate signal 2-22

2.7 Auxiliary Inputs Signal 2-24
- 2.7.1 Data, data clock and symbol clock signals 2-24
- 2.7.2 Burst gate signal 2-24

2.8 Symbol Adjust Function 2-25

2.9 Phase Encode Function 2-26

(Blank)

SECTION 2
BASIC OPERATION

2.1 Screen Transition

The display screen switches as shown below.

The screens appearing in this chapter are those for the MG3670B. The screens for the MG3671A/ MG3660A differ only in the model name indication in the top of the screen. Substitute the applicable model name for the model name in the screens.



2.2 Setting the Modulation Parameters

(1) Screen

When the Main Function section Mod key on the front panel is pressed, the parameter setting screen (modulation parameter setting mode) appears.



Fig. 2-1 Parameter Setting Screen (modulation parameter setting mode)

Use the Cursor keys to set the following parameters in this screen.

- I, Q signal input ..... Source
- Communication system ..... System
- Baseband filter ..... Filter
- Phase Encode ..... Phase Encode
- Burst function ..... Burst
- Internal modulation data ..... Pattern
- Burst trigger input ..... Trigger
- Burst trigger position ..... Trigger Select

Note: *Trigger Select can be set when the communication system is PHP.*

(2) Setting parameters

■ Source (Int / Ext)

Sets the I, Q signals to internal (Int) or external (Ext).

Initial setting: Int

■ System

Select one of the five communication systems; PDC, PHP, NADC, TFTS and PDC_H. When the communication system is selected, the modulation method, roll-off rate (a), and bit rate are set as shown below.

Initial setting: PDC (does not affect the Preset key)

Communication system	Modulation method	Roll-off rate	Bit rate
PDC	π / 4 DQPSK	$\alpha = 0.5$	42 kbps
PHP	π / 4 DQPSK	$\alpha = 0.5$	384 kbps
NADC	π / 4 DQPSK	$\alpha = 0.35$	48.6 kbps
TFTS	π / 4 DQPSK	$\alpha = 0.4$	44.2 kbps
PDC_H	π / 4 DQPSK	$\alpha = 0.5$	42.0 kbps

■ Filter (NYQ / RNYQ)

Nyquist (NYQ) or Root-Nyquist (RNYQ) can be selected as the baseband filter.

Initial setting: Root-Nyquist (RNYQ)
The roll-off rate (α) is fixed according to the communication system.

■ Phase Encode (Normal / Inverse)

Normally use the normal mode. Selecting the inverse mode inverts the right and left of modulation wave spectrum from the carrier frequency. For detail, refer to Paragraph 2.9.

■ Burst (On / Off)

The burst function can set to On when a burst function unit (MG0303B) is installed.

Initial setting: Off

■ Pattern

The following internal modulation data can be set:
When data of BaseBand Setup screen is externally input, Pattern is not displayed.

- When the burst function is on: Standard internal modulation data of each communication system (For details on the internal modulation data of each communication system, see Section 3.)
  Data stored in the internal modulation data memory (For details, see 2.4 Internal modulation data memory)
- When burst function is off: PN9, PN15 and any 4-bit data (0000 to 1111)

■ Trigger (Int / Ext)

Sets the burst trigger to either internal (Int) or external (Ext) when the burst function is on.

Initial setting: Int

■ Trigger Select (Uplink / Downlink)

Sets the burst trigger position of the PHP system to either Uplink or Downlink when the burst function is on.

Initial setting:Downlink

(3) Function keys



2.3 Setting Internal Modulation Data

(1) Screen

The internal modulation data setting screen is displayed when the 'Pattern Edit' F2 soft key shown in the parameter setting screen (modulation parameter setting mode) is pressed while the burst function is on.

The standard internal modulation data set in Pattern in the modulation parameter setting screen is displayed in this screen.



Fig. 2-2 Internal Modulation Data Setting Screen (PDC system)

Note: *The internal modulation data cannot be set if there is no burst function unit (MG0303B) installed.*

(2) Set parameters

■ Slot number

Selects the numbers of the desired slots.

PDC: Slot 0 to Slot 2
PHP: Slot 1 to Slot 4
NADC: Slot 0 to Slot 2
TFTS: Slot 0 to Slot 16
PDC_H: Slot 0 to Slot 5

■ Slot

Selects the applicable slot. The selectable slot depends on the standard internal modulation data set in Pattern of each communication system. For details on the internal modulation data of each communication system, see Section 3.

■ Modulation data

Sets the modulation data of a slot. The selectable types and ranges of modulation data differ from slot to slot. For details on the internal modulation data of each communication system, see Section 3.

(3) Function keys


Pattern Edit
Pattern Save
F1
Switches to the internal modulation data save screen.
Pattern Delete
F2
Switches to the internal modulation data delete screen. This key is not displayed when there is no internal modulation data stored.
Pattern List
F3
Switches to the internal modulation data list screen. This key is not displayed when there is no internal modulation data stored.
F4
F5
Return
F6
Returns to the parameter setting screen (modulation parameter setting mode).

2.4 Internal Modulation Data Memory

Modulation data set in the internal modulation data setting screen can be stored into, retrieved, deleted and listed from memory. Each of the memory operations are discussed in detail below.

2.4.1 Saving internal modulation data

When the 'Pattern Save' F1 soft key is pressed in the internal modulation data setting screen, the internal modulation data save screen appears. Specify the memory location number using the data keys, rotary knob, Step keys or Cursor keys and press the Set or Enter key to store the set data.

Memory location number range: 0 to 99

(1) Screen



Fig. 2-3 Internal Modulation Data Save Screen

Initial memory location number: Currently available location having the smallest number

If data is already stored in the specified location, a Yes/No window appears for confirmation purposes. Press the Set key to overwrite the current data. After storing the data, the internal modulation data setting screen is redisplayed.

Example: Stores modulation data in memory location 10.

Step	Action	Verification
1	Mod†	Sets the modulation parameter setting mode and lights the Mod key's LED indicator.
2	Pattern Edit F3	Displays the internal modulation data setting screen.
3	Pattern Save F1	Displays the internal modulation data saving screen.
4	1 0 Set	Specifies memory location 10 and stores internal modulation data in that location.

† There is no need to press the Mod key if its indicator is already lit.

(3) Function keys

Save		
Last Page	F1	Displays the previous page of the current data list. No operation is performed when there is no previous page.
Next Page	F2	Displays the next page of the current data list. Nothing is done when there is no next page.
* Title	F3	Displays the title input window and related function keys.
	F4	
	F5	
→ Return	F6	Returns to the internal modulation data setting screen.

■ Inputting a title

A title up to eight characters long can be entered when storing internal modulation data. "********" is displayed in the title field when no title is specified.

(1) Screen


MG3670B Digital Modulation Signal Generator
Title
Pattern Save
Memory No. (2)
Title : DEVICE
Entry[DEVICE]
ABCDEFGHIJKLMNOPQRSTUVWXYZ
abcdefghijklmnopqrstuvwxyz
0123456789-+/=!"#$%&' ()^`¥
|@[]{};:,.<>?_
Cursor←
Cursor→
Delete
Clear
No: Title No: Title No: Title No: Title No: Title
0: DEVICE 10: VOX 20: UP TCH 30: DOWN TCH 40: ********
1: DEVICE 11: VOX No.1 21: UP TCH 31: DOWN TCH 41: ********
2: 12: VOX No.2 22: 32: DOWN No1 42: ********
3: 13: 23: 33: DOWN No2 43:
4: 14: 24: 34: 44:
5: 15: 25: 35: 45:
6: 16: 26: 36: 46:
7: 17: 27: 37: 47:
8: 18: 28: 38: 48:
9: 19: 29: 39: 49:

Fig. 2-4 Internal modulation data save screen (title input window)

(2) Function keys



Example : Inputs the title 'Anritsu'.

Step	Action	Verification
1	Mod †	Switches to modulation parameter setting mode and lights the Mod key's LED indicator.
2	Pattern Edit, F2	Switches to the internal modulation data setting screen.
3	Pattern Save, F1	Switches to the internal modulation data save screen.
4	Title, F3	Opens the window for setting the title.
5	Clear, F5	Clears the title entry field.
6	Cursor ←, F1, Cursor →, F2	Moves the cursor within the entry field.
7	Cursor keys or rotary knob	Selects the characters from the character list.
8	Enter	Enters the selected character in the Entry field.
9	BS	Deletes an erroneously entered character.
10	Repeat steps 6, 7 and 8 until 'Anritsu' is completely entered.	
11	Set	Closes the title input window after inputting the title. (After inputting the title, specify the memory location number where internal modulation data will be stored.)

† There is no need to press the Mod key if its LED indicator is already on.

Note: *The title can also be entered using the data keys.*

2.4.2 Recalling internal modulation data

Data saved in the internal modulation data save screen can be retrieved through the Pattern setting in the parameter setting screen (modulation parameter setting mode).

(1) Screen



Fig. 2-5 Parameter Setting Screen (modulation parameter setting mode, Pattern setting window)

If internal modulation data is stored in memory, 'Memory▷' is displayed in the Pattern setting window in the parameter setting screen (modulation parameter setting mode). When this is selected, a sub-window opens and data stored in memory are displayed.

When the Set key is pressed and the pattern selected, both windows close simultaneously. Press the Cancel key to close the sub-window only.

(2) Function keys



Last Page (F1)	Displays the previous page in the sub-window. No operation is performed when there is no previous page.
Next Page (F2)	Displays the next page in the sub-window. No operation is performed when there is no previous page.

CAUTION: *When the communication system is PDC_H (half rate), the pattern saved at PDC (full rate) can be recalled. In this case, contents of full rate slots 0 to 2 are reflected to slots 0 to 2 and slots 3 to 5 are set to off.*

2.4.3 Deleting internal modulation data

When the 'Pattern Delete' F2 soft key is pressed in the internal modulation data setting screen, the internal modulation data delete screen appears. Use the data keys, rotary knob, Step keys and Cursor keys to specify the memory number and then press the Set and Enter keys. A Yes/No window then appears for verification. Select Yes to delete the data.

Initial memory location number: Currently saved memory location having the smallest number

(1) Screen


MG3670B Digital Modulation Signal Generator
Delete
Pattern Delete
Memory No. (0)
Last Page
Next Page
No: Title No: Title No: Title No: Title No: Title
0: DEVICE 10: VOX 20: UP TCH 30: DOWN TCH 40: ********
1: DEVICE 11: VOX No.1 21: UP TCH 31: DOWN TCH 41: ********
2: 12: VOX No.2 22: 32: DOWN No1 42: ********
3: 13: 23: 33: DOWN No2 43:
4: 14: 24: 34: 44:
5: 15: 25: 35: 45:
6: 16: 26: 36: 46:
7: 17: 27: 37: 47:
8: 18: 28: 38: 48:
9: 19: 29: 39: 49:
Delete All
Return

Fig. 2-6 Parameter Setting Screen (modulation parameter setting mode, pattern data deletion)

To delete all data in memory, press the 'Delete All' F4 soft key. 'All' is displayed in the memory number field and all data set in the list are reversely highlighted. A Yes/No window then appears for verification purposes. Press Yes to delete all of the data sets.

Example: Deletes the internal modulation data in memory location 10.

Step	Action	Verification
1	Mod †	Switches to the modulation parameter setting mode and the Mod key's LED indicator lights.
2	Pattern Edit F2	Switches to the internal modulation data setting screen.
3	Pattern Delete F2	Switches to the internal modulation data delete screen.
4	1 0 Set	Specifies memory location 10. (A Yes/No window opens for verification.)
5	Cursor < Set	Select Yes to delete the data.

† There is no need to press the Mod key if its indicator is already lit.

(2) Function keys

Delete		
Last Page	F1	Displays the previous page of the current data list. No operation is performed when there is no previous page.
Next Page	F2	Displays the next page of the current data list. Nothing is done when there is no next page.
	F3	
Delete All	F4	Deletes all data stored in memory.
	F5	
Return →	F6	Returns to the internal modulation data setting screen.

2.4.4 Listing internal modulation data

When the 'Pattern List' F3 soft key is pressed in the internal modulation data setting screen, the internal modulation data list screen appears. Use the data keys, rotary knob, Step keys and Cursor keys to specify the memory location number and then press the Set or Enter key to display in a window the internal modulation data stored in that location.

Initial memory location number: Currently saved memory location having the smallest

(1) Screen


MG3670B Digital Modulation Signal Generator
List
Pattern List
Memory No. (20)
Last Slot
Next Slot
Title : UP TCH
(1/3)
Slot 0 : UP TCH
R P TCH SW CC SF SACCH TCH G
4 2 112 20 8 1 15 112 6
Scramble : [On] (TCH, SF, SACCH)
Scramble Code : [1FF]H
TCH : [PN9]
SW : [785B4]H
CC : [FF]H
SACCH : [7FFF]H
R : 0H
P : 2H
SF : 0H
G : 0H
4: 14: 24: 34: 44:
5: 15: 25: 35: 45:
6: 16: 26: 36: 46:
7: 17: 27: 37: 47:
8: 18: 28: 38: 48:
9: 19: 29: 39: 49:

Fig. 2-7 Internal Modulation Data List Screen

Internal modulation data is displayed per slot; Use the 'Last Slot' F1 and 'Next Slot ' F2 soft keys to select the slot. Press the Set or Cancel key to close the window.

(2) Function keys



2.5 I, Q Signal Outputs

The I, Q signal outputs are always produced regardless of the I, Q modulation signal source setting (Int or Ext). The I, Q signals are described as follows:

Setting		I, Q signal output
Modulation	Source	
On	Int	Outputs I,Q signals corresponding to the currently set modulation.
	Ext	Outputs I,Q signals immediately before the source is set to Ext.
Off	——	Outputs a DC voltage signal for non-modulated signals.

Note: *Only the DC voltage signal for non-modulated signals is output for models that are not equipped with a modulation unit.*

(1) Setting the output level

The output level can be set within the range shown in the table below. However, the input and output settings will be the same. For details, refer to the 'Panel Operating Instructions part ' in the MG3670 series • MG3660A (main instrument) operation manual.

I, Q Level	Impedance		Input/Output level	Offset voltage
	Input	Output		
50 Ω 500 mV selected	50 Ω	50 Ω	500 mVrms (Fixed)	0 mV (Fixed)
CMOS selected	100 kΩ	600 Ω	50 to 500 mVrms , 50 mVrms step	0 to 4000mV, 1 mV step

■ **Defining the output levels of the I, Q signals:**

Output level is $\sqrt{I^2 + Q^2}$ for '0000' pattern, terminated voltage;

terminated impedance is as follows:

When 50 Ω, 500 mV is selected: 50 Ω
When CMOS is selected: 600 Ω

Note: *For details on the I, Q signals input level, refer to the 'Panel Operating Instructions part ' in the MG3670 series • MG3660A (main instrument) operation manual.*

(2) I, Q output balance, offset and phase adjustment functions

When the I, Q output trimmer function is set to On, the adjustment function is activated. For details on the setting method, refer to the 'Panel Operating Instructions part ' in the MG3670 series • MG3660A (main instrument) operation manual.

■ Balance adjustment function

The balance adjustment function fixes the amplitude of the Q signal and varies the amplitude of the I signal within ±20%.

■ Offset adjustment function

The offset adjustment function adds an offset voltage ranging within ±0.1 V to the I and Q output signals. (The I signal offset voltage can be independently adjusted from the Q signal offset voltage.)

■ Phase adjustment function

The phase adjustment function shifts the phase of the I signal within a ±10° range. This shift operation can be expressed in an equation as follows:

$I_{OUT} = I \cdot \cos\theta + Q \cdot \sin\theta$

$Q_{OUT} = Q$

I_{OUT}: I signal output when the I and Q signal adjustment function is On

Q_{OUT}: Q signal output when the I and Q signal adjustment function is On

I: I signal output when the I and Q signal adjustment function is Off

Q: Q signal output when the I and Q signal adjustment function is Off

θ: Phase shift angle; Can be varied within ±10° with the trimmer

Note: *The functions described above cannot be independently set On or Off.*

2.6 Auxiliary signal outputs

This section explains the control signals output from the MG3670 series • MG3660A rear panel. For details on the IQ DC offset, refer to the 'Panel Operating Instructions part ' in the MG3670 series • MG3660A (main instrument) operation manual.

2.6.1 Data, data clock and symbol clock signals

The output timings of the Data, Data Clock and Symbol Clock signals are shown below. In the figure, the polarities of the signals are expressed as positive or rising edge.



The symbol consists of Xn and Yn, where Xn indicates data that occurs before Yn.

2.6.2 Pattern sync signal

The Pattern Sync output signal that is produced depends on whether the burst function is On or Off. This is explained as follows:

(1) When burst function is Off:

When the burst function is off, the Pattern Sync Output signal allows a signal synchronized with the output pattern to be output.

■ When PN pattern is selected

When PN9 is selected, an invert signal is output at the beginning of a pattern consisting of nine contiguous '1' bits. When PN15 is selected, an invert signal is output at the beginning of a pattern consisting of fifteen contiguous '0' bits. The output signal when PN9 is selected is shown below:



■ When 4-bit pattern is selected:

An invert signal is output at the beginning of the 4-bit pattern. The figure is based on a '1000' 4-bit pattern.



(2) When the burst function is On

The Pattern Sync Output Signal allows when the burst function is On, a control signal synchronized with the frames to be output.

■ When the PN clock is selected

The clock signal of the pseudorandom pattern of the first output slot in the frame is output.

■ When the PN gate is selected

The gate signal of the pseudorandom pattern of the first output slot in the frame is output.



■ When the RF gate is selected

A control signal from the pulse modulation unit inside the main instrument is output.



The details about the slot are shown in the figure below. The format of the slot in this figure is for explanation purposes only and differs from the actual system.



2.6.3 Burst gate signal

When the burst function is on and the internal pattern is used for modulation, a signal synchronized with the output slot in the frame is output..



The details about the slot are shown in the figure below. The format of the slot in this figure are for explanation purposes only and differs from the actual system.



2.7 Auxiliary Inputs Signal

This paragraph explains the control signals input from the MG3670 series • MG3660A front panel.

2.7.1 Data, data clock and symbol clock signals

The input timings of the Data, Data Clock and Symbol Clock signals are shown below. In the figure, the polarities of the signals are expressed as positive or rising edge.



The symbol consists of Xn and Yn, where Xn indicates data that occurs before Yn.

Note: *To input only one or two signals, synchronize the timing(s) with the output signal(s) of the signal(s) that will not be inputted.*

2.7.2 Burst gate signal

When the burst function is On and data input is set to Ext, the burst gate signal can be fed externally. This signal can be fed in synchronously with the data signal timing in order to generate an RF burst signal identical to the burst signal generated from the internal pattern. (This will smoothen the slope of the rising and falling edges and prevent the spectrum from deteriorating.)

Shown below are the input timings of the Data, Data Clock, Symbol Clock and Burst Gate signals.



Note: *The rising and falling edges of the power corresponds to Symbol 0, 1 and Symbol n+1, n+2, respectively.*

2.8 Symbol Adjust Function

This function sets the symbol synchronization state in the case of $\pi/4$ DQPSK modulation.

■ Automatic synchronization function:

Function that synchronizes the internal symbol with the symbol clock input when in the symbol clock input mode.

Process: When the appropriate symbol clock is fed, the 'Symbol Adjust' F1 soft key disappears from the screen and the internal symbol is synchronized with the fed symbol clock.

■ Synchronization state select function:

Function that selects the symbol synchronization state when there is no symbol clock input in the symbol clock input mode.

Process: The symbol synchronization mode changes each time the 'Symbol Adjust' F1 soft key is pressed.

Shown below are the main instrument settings that can be used by the symbol adjust function.

MG3670 series • MG3660A setting		Symbol Adjust function
Data Clock	Data	
Int	Int	Invalid
Int	Ext	Valid
Ext	Int	Valid
Ext	Ext	Valid

Invalid: Symbol clock cannot be input.

Valid: Synchronizes the symbol with the input symbol clock. When there is no input symbol clock, the symbol case, the Symbol Adjust key is used to select the symbol synchronization mode.

■ Inputting the symbol clock:

The input timing of the symbol clock is shown below. The polarities of all the signals are expressed as positive or rising edge.



The symbol consists of Xn and Yn, where Xn indicates data that occurs before Yn.

2.9 Phase Encode Function

This function inverts the direction of phase change against modulation data, changing the differential phase encoding specification at the $\pi/4$DQPSK modulation. With this function, the right and left of modulation spectrum can be inverted with the carrier frequency as the center. The differential phase encoding specifications are shown in the table below.

Differential phase encoding specifications at $\pi/4$DQPSK modulation

XY	Phase change $\Delta\Phi$ [rad]			
	PDC, PHP, NADC, PDC_H system		TFTS system	
	Normal	Inverse	Normal	Inverse
11	$-3\pi/4$	$3\pi/4$	$\pi/4$	$-\pi/4$
01	$3\pi/4$	$-3\pi/4$	$3\pi/4$	$-3\pi/4$
00	$\pi/4$	$-\pi/4$	$-3\pi/4$	$3\pi/4$
10	$-\pi/4$	$\pi/4$	$-\pi/4$	$\pi/4$

CAUTION: *X and Y represent symbols composed of 2 bits each. X advances to Y timewise.*

SECTION 3
DETAILED OPERATIONS

This section describes the operation, generated patterns and the trigger function of the MG0301C $\pi/4$ DQPSK Modulation Unit and the MG0303B Burst Function Unit for each system.

TABLE OF CONTENTS

3.1 Operating the PDC System 3-3
3.1.1 Frame composition 3-3
3.1.2 Slot composition 3-3
3.1.3 Standard internal modulation data 3-6

3.2 Operating the PHP System 3-8
3.2.1 Frame composition 3-8
3.2.2 Slot composition 3-8
3.2.3 Standard internal modulation data 3-12

3.3 Operating the NADC System 3-15
3.3.1 Frame composition 3-15
3.3.2 Slot composition 3-15
3.3.3 Standard internal modulation data 3-16

3.4 Operating the TFTS System 3-18
3.4.1 Frame composition 3-18
3.4.2 Slot composition 3-18
3.4.3 Standard internal modulation data 3-20

3.5 Operating the PDC_H System 3-22
3.5.1 Frame composition 3-22
3.5.2 Slot composition 3-22
3.5.3 Standard internal modulation data 3-26

3.6 Detailed Trigger Function 3-28
3.6.1 Operation of the internal trigger 3-28
3.6.2 Operation of the external trigger 3-28
3.6.3 Output Timing of Burst Trigger and RF Signals 3-30
3.6.4 Relationships Between RF Signal and Symbol Judgment Point 3-33

(Blank)

SECTION 3
DETAILED OPERATIONS

3.1 Operating the PDC System

3.1.1 Frame composition

The TDMA frame consists of three slots. Signals are generated with one frame as one cycle. The PN9/PN15 pseudorandom pattern is independent for each slot and is continuous.



3.1.2 Slot composition

There are four types of slot for this system, namely, device evaluation slot, communication channel (uplink/downlink) and VOX control slot.

(1) Device evaluation slot (DEVICE)

R	PN	G
4	270	6

R: Ramp time ..... 0_H (4 bits)
PN: Pseudorandom pattern ..... Independent PN9 pseudorandom pattern per slot
(The PN pattern in the same slot is continuous.)
G: Guard time ..... 00_H (6 bits)

[Setting parameter]

- PN: PN9 or PN15 pseudorandom pattern

(2) Uplink communication channel (UP TCH)

R	P	TCH	SW	CC	SF	SACCH	TCH	G
4	2	112	20	8	1	15	112	6

R: Ramp time ..... 0_H (4 bits)
P: Preamble ..... 2_H (2 bits)
TCH: Traffic channel ..... Independent PN9 pseudorandom pattern per slot (The PN pattern in the TCH field of the same slot is continuous.)
SW: Synchronization word ..... Slot 0 = $785b4_H$ (20 bits) ,
Slot 1 = $62DC9_H$ (20 bits) ,
Slot 2 = $7E28A_H$ (20 bits)
CC: Color code ..... 00_H (8 bits)
SF: Steal flag ..... 0_H (1 bit)
SACCH: Slow associated control channel ..... 0000_H (15 bits)
G: Guard time ..... 00_H (6 bits)
Scramble function (TCH, SF, SACCH): ..... On
Scramble code: ..... 000_H (9 bits)
[Setting parameter]

- CC: 00_H to FF_H (8 bits)
- SACCH: 0000_H to $7FFF_H$ (15 bits)
- TCH: PN9 or PN15 pseudorandom pattern
- SW: 00000_H to $FFFFF_H$ (20 bits)
- Scramble function: On / Off
- Scramble code: 000_H to $1FF_H$ (9 bits)

(3) Downlink communication channel (DOWN TCH)

R	P	TCH	SW	CC	SF	SACCH	TCH
4	2	112	20	8	1	21	112

R: Ramp time ..... 0_H (4 bits)
P: Preamble ..... 2_H (2 bits)
TCH: Traffic channel ..... Independent PN9 pseudorandom pattern per slot (The PN pattern in the TCH field of the same slot is continuous.)
SW: Synchronization word ..... Slot 0 = $87A4B_H$ (20 bits) ,
Slot 1 = $9D236_H$ (20 bits) ,
Slot 2 = $81D75_H$ (20 bits)
CC: Color code ..... 00_H (8 bits)
SF: Steal flag ..... 0_H (1 bit)
SACCH: Slow associated control channel ..... 000000_H (21 bits)
Scramble function (TCH, SF, SACCH): ..... On
Scramble code: ..... All 000_H (9 bits)
[Setting parameter]

- CC: 00_H to FF_H (8 bits)
- SACCH: 000000_H to $1FFFFF_H$ (21 bits)
- TCH: PN9 or PN15 pseudorandom pattern
- SW: 00000_H to $FFFFF_H$ (20 bits)
- Scramble function: On / Off
- Scramble code: 000_H to $1FF_H$ (9 bits)

(4) VOX control (VOX)

G	R	P	SW	CC	SF	SACCH	G
108	4	6	20	8	1	15	118

R: Ramp time ..... 0_H (4 bits)
G: Guard time ..... 0_H (118 bits)
P: Preamble ..... 26_H (6 bits)
SW: Synchronization word ..... Slot 0 = $785b4_H$, (20 bits)
Slot 1 = $62DC9_H$, (20 bits)
Slot 2 = $7E28A_H$, (20 bits)
CC: Color code ..... 00_H (8 bits)
SF: Steal flag ..... 0_H (1 bit)
SACCH: Slow associated control channel ..... 0000_H (15 bits)
Scramble function (SF, SACCH): ..... On
Scramble code: ..... 000_H (9 bits)

[Setting parameter]

- CC: 00_H to FF_H (8 bits)
- SACCH: 0000_H to $7FFF_H$ (15 bits)
- SW: 00000_H to $FFFFF_H$ (20 bits)
- Scramble function: On / Off
- Scramble code: 000_H to $1FF_H$ (9 bits)

3.1.3 Standard internal modulation data

There are six types of standard internal modulation data in the PDC system. To select the type of data, use 'Pattern' in the parameter setting screen (modulation parameter setting mode).

Note: • *'△' indicates the position of the burst trigger.*
• *All the slots 0 to 2 cannot be set to Off.*

(1) DEVICE

RF output using slot 0 as the device evaluation slot

【 Setting parameter 】

- Slot: Slots 0 to 2 can be set to either DEVICE or OFF.

(2) UP TCH

RF output using slot 0 as the uplink communications channel



【 Setting parameter 】

- Slot: Slots 0 to 2 can be set to UP TCH, VOX or OFF

(3) UP TCH ALL

RF output using All the slots 0 to 2 as uplink communications channels



【 Setting parameter 】

- Slot: Slots 0 to 2 can be set to UP TCH, VOX or OFF

(4) UP VOX

RF output using slot 0 as the VOX control slot



【 Setting parameter 】

- Slot: Slots 0 to 2 can be set to UP TCH, VOX or OFF

(5) DOWN TCH (DN TCH)

RF output using slot 0 as the downlink communications channel; The RF output is a continuous wave.



【 Setting parameter 】

- Slot: Slots 0 to 2 can be set to UP TCH, VOX or OFF.
  (The output from an Off slot will consist of pure 1's.)

(6) DOWN TCH ALL (DN TCH ALL)

RF output using All the slots 0 to 2 as downlink communications channels; The RF output is a continuous wave.

【 Setting parameter 】

- Slot: Slots 0 to 2 can be set to UP TCH, VOX or OFF.
  (The output from an OFF slot will consist of pure 1's.)

3.2 Operating the PHP System

3.2.1 Frame composition

A TDMA frame consists of a total of 8 slots, four slot for the downlink and another four slot for the uplink. Signals are generated with one frame considered as one cycle. However, VOX control signals are generated with four frames equal to 20 ms. A slot output is produced for the first frame only, and no slot output is produced for the succeeding 2 to 4 frames. The PN9/PN15 pseudorandom pattern in the TCH of a slot is independent for each slot and is continuous.



3.2.2 Slot composition

There are four types of slots for this system, namely, device evaluation slot, TCH communication slot, VOX control slot and sync burst slot.

(1) Device evaluation (DEVICE)

R	PN	G
4	220	16

R: Ramp time ..... 0_H (4 bits)
PN: pseudorandom pattern ..... Independent PN9 pseudrordom pattern per slot (PN pattern in the same slot is continuous.)
G: Guard time ..... 0000_H (16 bits)
[Setting parameter]
•PN: PN9 or PN15 pseudorandom pattern

(2) Traffic channel (TCH)

R	SS	PR	UW	CI	SA	TCH	CRC	G
4	2	6	16	4	16	160	16	16

R: Ramp time ..... 0_H (4 bits)
SS: Start symbol ..... 2_H (2 bits)
RR: Preamble ..... 19_H (6 bits)
UW: Unique word ..... Uplink = $E149_H$ (16 bits)
Downlink = $3D4C_H$ (16 bits)
CI: Channel identifier ..... 0_H (4 bits)
SA: SACCH (Slow associated control channel) ..... 8000_H (16 bits)
TCH: Traffic channel ..... Independent PN9 pseudorandom pattern per slot (The PN pattern in the TCH field of the same slot is continuous.)
CRC: Cyclic redundancy check ..... CRC bits of CI, SA, and TCH
G: Guard time ..... 0000_H (16 bits)
Scramble function (TCH, CRC) ..... On
Scramble code ..... 200_H (10 bits)
Simple security function (TCH) ..... On
Password code ..... 0000_H (16 bits)

[Setting parameter]

- UW: 0000_H to $FFFF_H$ (16 bits)
- SA: 0000_H to $FFFF_H$ (16 bits)
- TCH: PN9 or PN15 pseudorandom pattern
- Scramble function: On / Off
- Scramble code: 000_H to $3FF_H$ (10bits)
- Simple security function: On / Off
- Password code: 0000_H to $FFFF_H$ (16bits)

(3) Voice operated transmission (VOX)

R	SS	PR	UW	CI	SA	VOX	CRC	G
4	2	6	16	4	16	160	16	16

R: Ramp time ..... 0_H (4 bits)
SS: Start symbol ..... 2_H (2 bits)
RR: Preamble ..... 19_H (6 bits)
UW: Unique word ..... Uplink = E149 $_H$ (16 bits)
Downlink = $3D4C_H$ (16 bits)
CI: Channel identifier ..... F_H (4 bits)
SA: SACCH (Slow associated control channel) ..... 8000_H (16 bits)
TCH: Traffic channel ..... Independent PN9 pseudorandom pattern per slot (The PN pattern in the VOX field of the same slot is continuous.)
CRC: Cyclic redundancy check ..... CRC bits of CI, SA, and TCH
G: Guard time ..... 0000_H (16 bits)
Scramble function (TCH, CRC) ..... On
Scramble code ..... 200_H (10 bits)
Simple security function (TCH) ..... On
Password code ..... 0000_H (16 bits)

[Setting parameter]

- UW: 0000_H to $FFFF_H$ (16 bits)
- SA: 0000_H to $FFFF_H$ (16 bits)
- TCH: PN9 or PN15 pseudorandom pattern
- Scramble function: On / Off
- Scramble code: 000_H to $3FF_H$ (10 bits)
- Simple security function: On / Off
- Password code: 0000_H to $FFFF_H$ (16 bits)

(4) Sync burst (SYNC)

R	SS	PR	UW	CI	CS-ID	PS-ID	Idle	CRC	G
4	2	62	32	4	42	28	34	16	16

R: Ramp time ..... 0_H (4 bits)
SS: Start symbol ..... 2_H (2 bits)
RR: Preamble ..... 1999999999999999_H (62 bits)
UW: Unique word ..... Uplink = $6B899AF0_H$ (32 bits)
Downlink = $50EF2993_H$ (32 bits)
CI: Channel identifier ..... 9_H (4 bits)
CS-ID: Cell station ID code ..... 20200020001_H (42 bits)
PS-ID: Personal station ID code ..... 0000001_H (28 bits)
Idle: Idle bit ..... 000000000_H (34 bits)
CRC: Cyclic redundancy check ..... CRC bits of CI, CS-ID, PS-ID, and Idle
G: Guard time ..... 0000_H (16 bits)
Scramble function (CS-ID, PS-ID, Idle, CRC) ..... On
Scramble code ..... 200_H (16 bits)
[Setting parameter]

- UW: $00000000_H \sim FFFFFFFF_H$ (32 bits)
- CI: $0_H \sim F_H$ (4 bits)
- CS-ID: $00000000000_H \sim 3FFFFFFFFF_H$ (42 bits)
- PS-ID: $0000000_H \sim FFFFFFF_H$ (28 bits)
- Idle: $000000000_H \sim 3FFFFFFFF_H$ (34 bits)
- Scramble function: On / Off
- Scramble code: 000_H to $3FF_H$ (10 bits)

3.2.3 Standard internal modulation data

There are ten types of standard internal modulation data in the PHP system. To select the type of data, use 'Pattern' in the parameter setting screen (modulation parameter setting mode).

Note: ● *'△' indicates the position of the burst trigger.*
● *All the slots 1 to 4 cannot be set to Off.*

(1) DEVICE

RF output using the uplink circuit slot 1 as the device evaluation slot

【 Setting parameter 】

● Slot: The uplink circuit slots 1 to 4 can be set to either DEVICE or OFF.

(2) DOWN DEVICE (DN DEVICE)

RF output using the downlink circuit slot 1 as the device evaluation slot



【 Setting parameter 】

● Slot: The downlink circuit slots 1 to 4 can be set to either DEVICE or OFF.

(3) UP TCH

RF output using the uplink circuit slot 1 as the TCH transmit slot

【 Setting parameter 】

● Slot: The uplink circuit slots 1 to 4 can be set to either TCH or OFF.

(4) UP TCH ALL

RF output using all the uplink circuits which include slots 1 to 4 as the TCH transmit slot



【 Setting parameter 】

- Slot: The uplink circuit slots 1 to 4 can be set to either UP TCH or OFF.

(5) DOWN TCH (DN TCH)

RF output using the downlink circuit slot 1 as the TCH transmit slot



【 Setting parameter 】

- Slot: The downlink circuit slots 1 to 4 can be set to DOWN TCH, VOX, or OFF.

(6) DOWN TCH ALL (DN TCH ALL)

RF output using all the downlink circuits which include slots 1 to 4 as the TCH transmit slot



【 Setting parameter 】

- Slot: The downlink circuit slots 1 to 4 can be set to DOWN TCH, VOX, or OFF.

(7) UP VOX

RF output using the uplink circuit slot 1 as VOX control slot



【 Setting parameter 】

- Slot: The uplink circuit slots 1 to 4 can be set to either VOX or OFF.

Note: *The VOX control slot is produced every four frames. The burst trigger is also generated once every 4 frames.*

(8) DOWN VOX (DN VOX)

RF output using downlink slot 1 as the VOX control slot

【 Setting parameter 】

- Slot: Downlink slots 1 to 4 can be set to TCH, VOX or OFF.

(9) UP SYNC

RF output using uplink slot 1 as the sync burst slot



【 Setting parameter 】

- Slot: The uplink slots 1 to 4 can be set to either TCH or OFF.
  Either one of slots can be set to SYNC.

(10) DOWN SYNC (DN SYNC)

RF output using downlink slot 1 as the sync burst slot



【 Setting parameter 】

- Slot: The downlink slots 1 to 4 can be set to either TCH, VOX or OFF.
  Either one of slots can be set to SYNC.

3.3 Operating the NADC System

3.3.1 Frame composition

A frame consists of 3 slots. Signals are generated with one frame considered as one cycle. The PN9 pseudorandom pattern in the data field of each slot is independent for every slot and is continuous.



3.3.2 Slot composition

There are three types of slot for this system, namely, device evaluation slot and uplink and downlink communications channel slots.

(1) Device evaluation slot (DEVICE)

G	R	PN
6	6	312

G: Guard time ..... 00_H (6 bits)
R: Ramp time ..... 00_H (6 bits)
PN: Pseudorandom pattern ..... Independent PN9 pseudorandom pattern per slot
(PN pattern in the same slot is continuous)

[Setting parameter]
- PN: PN9 or PN15 pseudorandom pattern

(2) Uplink communications channel (UP TCH)

G	R	DATA	SYNC	DATA	SACCH	CDVCC	DATA
6	6	16	28	122	12	12	122

G: Guard time ..... 00_H (6 bits)
R: Ramp time ..... 00_H (6 bits)
DATA: User data transfer ..... Independent PN9 pseudorandom pattern per slot(The PN pattern in the DATA field of the same slot is continuous.)
SYNC: Synchronization word ..... Slot 0 = $A91DE4A_H$ (28 bits) ,
Slot 1 = $A9D127A_H$ (28 bits) ,
Slot 2 = $C7E3C0C_H$ (28 bits)
SACCH: Slow associated control channel ..... 000_H (12 bits)
CDVCC: Color code ..... 000_H (12 bits)

[Setting parameter]
- CDVCC: 000_H to FFF_H (12 bits)
- SACCH: 000_H to FFF_H (12 bits)
- SYNC 0000000_H to $FFFFFFF_H$ (28 bits)
- DATA: PN9 or PN15 pseudorandom pattern

(3) Downlink communications channel (DOWN TCH)

SYNC	SACCH	DATA	CDVCC	DATA	RSVD
28	12	130	12	130	12

DATA: User data transfer ..... Independent PN9 pseudorandom pattern per slot (The PN pattern in the TCH field of the same slot is continuous).

SYNC: Synchronization word ..... Slot 0 = $A91DE4A_H$ (28 bits) ,
Slot 1 = $A9D127A_H$ (28 bits) ,
Slot 2 = $C7E3C0C_H$ (28 bits)

SACCH: Slow associated control channel ..... 000_H (12 bits)

CDVCC: Color code ..... 000_H (12 bits)

RSVD: Reserved ..... 000_H (12 bits)

[Setting parameter]

- CDVCC: 000_H to FFF_H (12 bits)
- SACCH: 000_H to FFF_H (12 bits)
- SYNC 0000000_H to $FFFFFFF_H$ (28 bits)
- DATA: PN9 or PN15 pseudorandom pattern

3.3.3 Standard internal modulation data

There are five types of standard internal modulation data available in the NADC system. To select the type of data, use 'Pattern' in the parameter setting screen (modulation parameter setting mode).

Note: • *'△' indicates the position of the burst trigger.*
• *All the slots 0 to 2 cannot be set to Off.*

(1) DEVICE

RF output using slot 0 as the device evaluation slot



【 Setting parameter 】

- Slot: Slots 0 to 2 can be set to DEVICE or OFF.

(2) UP TCH

RF output using slot 0 as uplink communications channel slots



【 Setting parameter 】

- Slot: Slots 0 to 2 can be set to UP TCH or OFF.

(3) UP TCH ALL

RF output using All the slots 0 to 2 as uplink communications channel slots



【 Setting parameter 】

- Slot: Slots 0 to 2 can be set to UP TCH or OFF.

(4) DOWN TCH (DN TCH)

RF output using slot 0 as the downlink communications channel slot. Slots 1 to 2 are continuous waves made up of pure 1's.



【 Setting parameter 】

- Slot: Slots 0 to 2 can be set to DOWN TCH or OFF. (All '1' are output for slot off)

(5) DOWN TCH ALL (DN TCH ALL)

RF output using all of the slots 0 to 2 as the downlink communication channel slot



【 Setting parameter 】

- Slot: Slots 0 to 2 can be set to DOWN TCH or OFF. (All '1' are output for slot off)

3.4 Operating the TFTS System

3.4.1 Frame composition

The TDMA frame consist of 17 slots. Signals are generated with one frame as one cycle. The PN9/PN15 pseudorandom pattern is independent for each slot and is continuous.



3.4.2 Slot composition

There are two types of slot for this system,namely,device evaluation slot and communications channel slot.

(1) Device evaluation slot (DEVICE)



G: Guard time ..... $1F_H$ (5bits)
PN: Pseudorandom pattern ..... Independent PN9 pseudorandom pattern per slot (PN pattern in continuous)

[Setting parameter]

- PN: PN9 or PN15 pseudorandom pattern

(2) Traffic channel (TCH)

G	S	DATA
5	11	192

G: Guard time ..... $1F_H$ (5bits)
S: Synchronization word ..... 414_H (11bits)
DATA: Data ..... Independent PN9 pseudorandom pattern per slot (The PN pattern in the DATA field of the same slot is continuous.)

[Setting parameter]

- S: 000_H to $7FF_H$ (11bits)
- DATA: PN9 or PN15 pseudorandom pattern

3.4.3 Standard internal modulation data

There are five types of standard internal modulation data in TFTS system. To select the type of data, use 'Pattern' in the parameter setting screen (modulation parameter setting mode).

Note: • *'△' indicates the position of the burst trigger.*

• *All the slots 0 to 16 cannot be set to Off.*

(1) DEVICE

RF output using slot 0 as the device evalution slot



[Setting parameter]

- Slot:Slot 0 to 15 can be set to either DEVICE or OFF.
  Slot 16 is set to OFF.(Fixed)
  RF output is continuous wave when adjacent slots are set to DEVICE.

(2) UP TCH

RF output using slot 0 as the traffic channel

[Setting parameter]

- Slot:Slot 0 to 15 can be set to either TCH or OFF.
  Slot 16 is set to OFF.(Fixed)
  RF output is continuous wave when adjacent slots are set to TCH.

(3) UP TCH ALL

RF output using slots 0 to 15 as the traffic channel



[Setting parameter]

- Slot:Slot 0 to 15 can be set to either TCH or OFF
  Slot 16 is set to OFF.(Fixed)
  RF output is continuous wave when adjacent slots are set to TCH.

(4) DOWN TCH (DN TCH)

RF output using slot 0 as the traffic channel; The RF output is a continuous wave.



[Setting parameter]

- Slot:Slot 0 to 16 can be set to either TCH or OFF.
  (All'0' are output for slot off)

(5) DOWN TCH ALL (DN TCH ALL)

RF output using all the slots 0 to 16 as traffic channel; The RF output is a continuous wave.

- Slot:Slot 0 to 16 can be set to either TCH or OFF.
  (All'0' are output for slot off)

3.5 Operating the PDC__H System

3.5.1 Frame composition

The TDMA frame consists of six slots. Signals are generated with one frame as one cycle. The PN9/PN15 pseudorandom pattern is independent for each slot and is continuous.



3.5.2 Slot composition

There are four types of slot for this system, namely, device evaluation slot, communication channel (uplink/downlink) and VOX control slot.

(1) Device evaluation slot (DEVICE)

R	PN	G
4	270	6

R: Ramp time ..... 0_H (4 bits)
PN: Pseudorandom pattern ..... Independent PN9 pseudorandom pattern per slot
(The PN pattern in the same slot is continuous.)
G: Guard time ..... 00_H (6 bits)

[Setting parameter]

- PN: PN9 or PN15 pseudorandom pattern

(2) Uplink communication channel (UP TCH)

R	P	TCH	SW	CC	SF	SACCH	TCH	G
4	2	112	20	8	1	15	112	6

R: Ramp time ..... 0_H (4 bits)
P: Preamble ..... 2_H (2 bits)
TCH: Traffic channel ..... Independent PN9 pseudorandom pattern per slot (The PN pattern in the TCH field of the same slot is continuous.)
SW: Synchronization word ..... Slot 0 = $785b4_H$ (20 bits),
Slot 1 = $62DC9_H$ (20 bits),
Slot 2 = $7E28A_H$ (20 bits),
Slot 3 = $56B15_H$ (20 bits),
Slot 4 = $AE9B3_H$ (20 bits),
Slot 5 = $B2621_H$ (20 bits)
CC: Color code ..... 00_H (8 bits)
SF: Steal flag ..... 0_H (1 bit)
SACCH: Slow associated control channel ..... 0000_H (15 bits)
G: Guard time ..... 00_H (6 bits)
Scramble function (TCH, SF, SACCH): ..... On
Scramble code: ..... 000_H (9 bits)

[Setting parameter]

- CC: 00_H to FF_H (8 bits)
- SACCH: 0000_H to $7FFF_H$ (15 bits)
- TCH: PN9 or PN15 pseudorandom pattern
- SW: 00000_H to $FFFFF_H$ (20 bits)

(3) Downlink communication channel (DOWN TCH)

R	P	TCH	SW	CC	SF	SACCH	TCH
4	2	112	20	8	1	21	112

R: Ramp time ..... 0_H (4 bits)

P: Preamble ..... 2_H (2 bits)

TCH: Traffic channel ..... Independent PN9 pseudorandom pattern per slot (The PN pattern in the TCH field of the same slot is continuous.)

SW: Synchronization word ..... Slot 0 = $87A4B_H$ (20 bits),
Slot 1 = $9D236_H$ (20 bits),
Slot 2 = $81D75_H$ (20 bits),
Slot 3 = $A94EA_H$ (20 bits),
Slot 4 = $5164C_H$ (20 bits),
Slot 5 = $4D9DE_H$ (20 bits)

CC: Color code ..... 00_H (8 bits)

SF: Steal flag ..... 0_H (1 bit)

SACCH: Slow associated control channel ..... 000000_H (21 bits)

Scramble function (TCH, SF, SACCH): ..... On

Scramble code: ..... All 000_H (9 bits)

[Setting parameter]

- CC: 00_H to FF_H (8 bits)
- SACCH: 000000_H to $1FFFFF_H$ (21 bits)
- TCH: PN9 or PN15 pseudorandom pattern
- SW: 00000_H to $FFFFF_H$ (20 bits)
- Scramble function: On / Off
- Scramble code: 000_H to $1FF_H$ (9 bits)

(4) VOX control (VOX)

G	R	P	SW	CC	SF	SACCH	G
108	4	6	20	8	1	15	118

R: Ramp time ..... 0_H (4 bits)
G: Guard time ..... 0_H (118 bits)
P: Preamble ..... 26_H (6 bits)
SW: Synchronization word ..... Slot 0 = $785b4_H$ (20 bits) ,
Slot 1 = $62DC9_H$ (20 bits) ,
Slot 2 = $7E28A_H$ (20 bits) ,
Slot 3 = $56B15_H$ (20 bits) ,
Slot 4 = $AE9B3_H$ (20 bits) ,
Slot 5 = $B2621_H$ (20 bits)
CC: Color code ..... 00_H (8 bits)
SF: Steal flag ..... 0_H (1 bit)
SACCH: Slow associated control channel ..... 0000_H (15 bits)
Scramble function (SF, SACCH): ..... On
Scramble code: ..... 000_H (9 bits)

[Setting parameter]

- CC: 00_H to FF_H (8 bits)
- SACCH: 0000_H to $7FFF_H$ (15 bits)
- SW: 00000_H to $FFFFF_H$ (20 bits)
- Scramble function: On / Off
- Scramble code: 000_H to $1FF_H$ (9 bits)

3.5.3 Standard internal modulation data

There are six types of standard internal modulation data available in the PDC__H system. To select the type of data, use 'Pattern' in the parameter setting screen (modulation parameter setting screen).

Note: • *'△' indicates the position of the burst trigger.*
• *All the slots 0 to 5 cannot be set to Off.*

(1) DEVICE

RF output using slot 0 as the device evalution slot

[Setting parameter]

- Slot: Slots 0 to 5 can be set to DEVICE or OFF.

(2) UP TCH

RF output using slot 0 as uplink communications channel slots

[Setting parameter]

- Slot: Slots 0 to 5 can be set to UP TCH, VOX or OFF.

(3) UP TCH ALL

RF output using all the slots 0 to 5 as uplink communications channel slots



[Setting parameter]

- Slot: Slots 0 to 5 can be set to UP TCH, VOX or OFF.

(4) UP VOX

RF output using slot 0 as the VOX control slot



[Setting parameter]

- Slot: Slots 0 to 5 can be set to UP TCH, VOX or OFF.

(5) DOWN TCH (DN TCH)

RF output using slot 0 as the downlink communications channel slot. The RF output is a continuous wave.
All "1" are output for slot off.



[Setting parameter]

- Slot: Slots 0 to 5 can be set to either DOWN TCH or OFF.

(6) DOWN TCH ALL (DN TCH ALL)

RF output using all the slots 0 to 5 as downlink communications channels; The RF output is a continuous wave.
All "1" are output for slot off.



[Setting parameter]

- Slot: Slots 0 to 5 can be set to DOWN TCH or OFF.

3.6 Detailed Trigger Function

There are two trigger functions for generating burst signals when the burst function is on. These are:

① Internal trigger that works synchronously with the internal trigger signal
② External trigger that works synchronously with the external trigger signal.

3.6.1 Operation of the internal trigger

An internal trigger works by generating a burst signal synchronous with the internal trigger signal. This trigger signal is output from the Burst Trig Output connector on the rear panel. Since the trigger signal is produced at every cycle of the burst signal, its period can be fixed in every system.

3.6.2 Operation of the external trigger

An external trigger works by generating a burst signal synchronous with the external fed trigger signal. This trigger signal is fed to the Burst Trig Input connector on the rear panel.

(1) External trigger signal input conditions

(a) Input level: TTL level

(b) Polarity : Either rising or falling edge can be selected

(c) Waveform : The waveform below illustrates a rising edge trigger waveform



T1 : ≧0.1 μs
T2 : ≧0.1 μs
T3 : burst cycle (frame cycle) ± 1 symbol
Rising/falling time: 100 ns or less

(2) Relationship between external input trigger signal and output burst signal

The figure below illustrates that the external input trigger signal is produced after a delay of one burst cycle.



Note: *If the period of the external input trigger signal does not satisfy the input condition in (1), the trigger signal is masked and invalidated as illustrated in the figure below. Therefore, the burst signal synchronized with the trigger signal cannot be obtained.*



3.6.3 Output Timing of Burst Trigger and RF Signals

Pay attention to output timings of trigger and RF signals when synchronized with another equipment using the burst trigger signal of the MG3670 series • MG3660A. Relationships between trigger and RF signals are explained below.

(1) When internal trigger signal is used

The output timing of RF signal is shown below when synchronized with another equipment using the Burst TrigOutput signal from the MG3670 series • MG3660A rear panel.



T_{di}: Represents the delay time when burst wave is output using the internal trigger signal, which corresponds to the time from trigger until the start up of the first slot in the frame.

Relationships between communication system and T_{di}

Communication system	Delay time T_{di} ( ) indicates symbol converted value.
PDC	20.3±0.5 μs (0.426 ± 0.011 symbol)
PHP	2.44±0.10 μs (0.468 ± 0.019 symbol)
NADC	17.8±0.5 μs (0.433 ± 0.014 symbol)
TFTS	−5.8±0.5 μs (−0.128 ± 0.011 symbol)
PDC_H	20.3±0.5 μs (0.426 ± 0.011 symbol)

CAUTION: *T_{di} includes error from system to system and is unique to each system, excluding the jitter.*

(2) When external trigger signal is used

The output timing of RF signal is shown below when synchronized with another equipment using the Burst TrigIntput signal to the MG3670 series • MG3660A rear panel. The RF signal is output with a delay equivalent to approximately 1 frame period (T_{de}) of the communication system from the trigger signal. This matches the timing of the second trigger signal to that of the RF output when a trigger signal meeting the communication system is input.



T_{de}: Represents the delay time when burst wave is output using the external trigger signal, which corresponds to the time from trigger until the start up of the first slot in the frame.

When an external trigger signal is used, the Tde value varies according to the mean used for synchronizing the MG3670 series • MG3660A with the trigger signal source equipment. The following explains T_{de} values by synchronization methods.

(A) When connecting only with trigger signal

The delay time is calculated using the formula below when only the trigger signal is input to the MG3670 series • MG3660A:

T_{de1} = Frame period of communication system + T_{di} ± Synchronization error (1/16 symbol)

T_{de1}: Delay time for connection only by trigger signal
T_{di}: Delay time for operation with internal trigger signal
Synchronization error: Jitter occurs within ± 1/16 symbol since the MG3670 series • MG3660A is not synchronized with the external trigger signal source.

CAUTION: *When the MG3670 series • MG3660A is synchronized with the external trigger signal source using the 10/13 MHz reference signal, no jitter occurs. The jitter value is inconsistent within a range ±1/16 symbol the synchronization error.*

Relationships between communication system and T_{de1}

Communication system	Delay time T_{de1}	( ) indicates symbol converted value.
PDC	20 ms + (20.3±3.5) μs	{1 frame + (0.426 ± 0.074 symbol)}
PHP	5 ms + (2.44±0.43) μs	{1 frame + (0.468 ± 0.083 symbol)}
NADC	20 ms + (17.8±3.1) μs	{1 frame + (0.433 ± 0.076 symbol)}
TFTS	80 ms + ((−5.8)±3.4) μs	{1 frame + (−0.128 ± 0.075 symbol)}
PDC_H	40 ms + (20.3±3.5) μs	{1 frame + (0.426 ± 0.074 symbol)}

(B) When Data Clock and Symbol Clock are connected

Delay times are calculated using the formula below when trigger signal is input to the MG3670 series • MG3660A with Data Clock and Symbol Clock connected:

T_{de2} = (Frame period of communication system) + T_{di}

T_{de2}: Delay time when trigger signal, Data Clock and Symbol Clock are connected
T_{di}: Delay time when operated using the internal trigger signal

Relationships between communication system and T_{de2}

Communication system	Delay time T_{de2}	( ) indicates symbol converted value.
PDC	20 ms + (20.3±0.5) μs	{1 frame + (0.426 ± 0.011)} symbol
PHP	5 ms + (2.44±0.10) μs	{1 frame + (0.468 ± 0.019)} symbol
NADC	20 ms + (17.8±0.5) μs	{1 frame + (0.433 ± 0.014)} symbol
TFTS	80 ms + ((−5.8)±0.5) μs	{1 frame + (−0.128 ± 0.011)} symbol
PDC_H	40 ms + (20.3±0.5) μs	{1 frame + (0.426 ± 0.011)} symbol

The figure below shows timings of Data Clock, Symbol Clock and trigger signals. (When polarities of all signals are positive)



CAUTION: *Although it is possible to operate without inputting the Symbol Clock, phase relationships between the Symbol Clock and trigger signals will be undefined. In this case, adjust the phase relationships between the MG3670 series • MG3660A and Symbol Clock of the trigger signal source as shown above using the Symbol Adjust key. When Data Clock is used for synchronization, the trigger signal input timing is adjusted in 1 symbol steps since the Symbol Clock monitors the Burst Trig Input signal.*

3.6.4 Relationships Between RF Signal and Symbol Judgment Point

Relationships between the RF output signal and symbol judgment point vary according to the communication system. The relationships are, therefore, explained for each system. Here, the symbol judgment point is defined as the point where the impulse response of the base band filter is the maximum.

(1) PDC / PDC_H system

Relationships between modulation data against the RF signal and the symbol judgment point is explained using slot 0 of the uplink traffic channel as an example.



S_1: First symbol generated by the burst transient response ramp bit
S_2: Second symbol generated by the burst transient response ramp bit
S_3: Symbol generated by the pre-amble
The delay time from burst trigger signal to start up of RF output is the same as that from burst trigger signal to S_0.
(For details on delay time, refer to Paragraph 3.6.3.)

(2) PHP system

Relationships between modulation data against the RF signal and the symbol judgment point is explained using slot 1 of the downlink traffic channel as an example.



S_1: First symbol generated by the burst transient response ramp bit
S_2: Second symbol generated by the burst transient response ramp bit
S_3: Symbol generated by the start symbol
The delay time from burst trigger signal to start up of RF output is the same as that from burst trigger signal to S_0.
(For details on delay time, refer to Paragraph 3.6.3.)

(3) NADC system

Relationships between modulation data against the RF signal and the symbol judgment point is explained using slot 0 of the uplink traffic channel as an example.



S_0: First symbol generated by the burst transient response ramp bit
S_1: Second symbol generated by the burst transient response ramp bit
S_2: Third symbol generated by the burst transient response ramp bit
S_3: First symbol generated by data
The delay time from burst trigger signal to start up of RF output is the same as that from burst trigger signal to S_0.
(For details on delay time, refer to Paragraph 3.6.3.)

(4) TFTS system

Relationships between modulation data against the RF signal and the symbol judgment point is explained using slot 1 of the downlink traffic channel as an example.



S_1: Symbol generated by the burst transient response guard ramp bit (corresponds to 1 to 2 bits)

S_2: Symbol generated by the burst transient response guard ramp bit (corresponds to 3 to 4 bits)

S_3: Symbol generated by 1 bit word synchronized to 5 bits of the burst transient response guard ramp bit
The delay time from burst trigger signal to start up of RF output is the same as that from burst trigger signal to S_{01} (intermittent point between S_0 and S_1).
(For details on delay time, refer to Paragraph 3.6.3.)

(Blank)

SECTION 4
MEASUREMENT

This section describes how to perform code error rate measurement for receivers, demodulator evaluation measurement, and modulator evaluation measurement using the MG0301C $\pi/4$ DQPSK Modulation Unit and the MG0303B Burst Function Unit in combination with the MG3670 series • MG3660A Digital Modulation Signal Generator.

TABLE OF CONTENTS

4.1 Code Error Rate Measurement for Receiver 4-3

4.2 Demodulator Evaluation Measurement 4-5

4.3 Modulator Evaluation Measurement 4-6

(Blank)

SECTION 4
MEASUREMENT

4.1 Code Error Rate Measurement for Receiver

The procedure for measuring a receiver code error rate using the MG3670 series • MG3660A + MG0301C system is described below. It is assumed that the receiver is equipped with a control mode that enables it to receive continuous waves.

(1) Setup



(2) Measurement procedure

Step	Procedure
1	Set the MG3670 series • MG3660A to the frequency to be tested.
2	Set the MG3670 series • MG3660A output to a level suitable for the receiver and the Matched coupling circuit.
3	Set the MG3670 series • MG3660A to the modulation system of the receiver.
4	Set the MG3670 series • MG3660A modulation pattern to PN9 pseudorandom pattern.
5	Connect the MG3670 series • MG3660A RF output to the power meter through the Matched coupling circuit. Using the power meter, adjust the MG3670 series • MG3660A output to the sensitivity test level.
6	Switch the Matched coupling circuit output to the receiver.
7	Using the receiver controller, set the receiver to the continuous wave reception mode.
8	Connect the receiver demodulation data output and data clock to the code error rate measuring instrument.

The procedure when the code error rate measuring instrument used is Anritsu's MD6420A Data Transmission Analyzer is described below.

Step	Procedure
9	Connect the data and clock obtained from the receiver to the RD (Data) and RT (Clock) connectors of the TTL Interface Unit (MD0626A) on the rear panel of the MD6420A.
10	Set the MD6420A receive timing as follows: • If data is sampled at the rising edge of the clock, set to RT (INV) mode. • If data is sampled at the falling edge of the clock, set to RT mode.
11	Set the MD6420A pattern to 2^9-1 (PN9).
12	Press the MD6420A MEAS key to measure the code error rate.

4.2 Demodulator Evaluation Measurement

The procedure for performing the evaluation measurement for a demodulator using the MG3670 series • MG3660A + MG0301C system is described below.

It is assumed that Anritsu's MS8604A Digital Mobile Radio Transmitter Tester is used in evaluating the demodulator I/Q signal output. Please note that the MS8604A requires the I-Q input function (option 03).

If the MG0303B Burst Function Unit is incorporated in the MG3670 series • MG3660A, it is also possible to perform evaluation using burst signals.

(1) Setup



(2) Measurement procedure

Step	Procedure
1	Set the MG3670 series • MG3660A to the frequency to be tested.
2	Set the MG3670 series • MG3660A output to a level suitable for the demodulator and the Matched coupling circuit.
3	Set the MG3670 series • MG3660A to the modulation system to be tested.
4	Set the MG3670 series • MG3660A modulation pattern to PN9 pseudorandom pattern. (If the MG0303B is incorporated, burst signal can also be set.)
5	Set the MS8604A so that the modulation system and pattern set in steps 3 and 4 can be received.
6	Using the MS8604A, measure the modulation accuracy and evaluate it. (For information on the MS8604A operation, refer to the MS8604A Operation Manual.)

4.3 Modulator Evaluation Measurement

The procedure for performing evaluation measurement for a modulator using the MG3670 series • MG3660A + MG0301C system is described below.

It is assumed that Anritsu's MS8604A Digital Mobile Radio Transmitter Tester is used in evaluating the modulator modulation signal output.

(1) Setup



(2) Measurement procedure

Step	Procedure
1	Set the MG3670 series • MG3660A I, Q signal output to a level suitable for the modulator and the Matched coupling circuit.
2	Set the MG3670 series • MG3660A to the modulation system to be tested.
3	Set the MG3670 series • MG3660A modulation pattern to PN9 pseudorandom pattern.
4	Set the MS8604A so that the modulation system and pattern set in steps 2 and 3 can be received.
5	Using the MS8604A, measure the modulation accuracy and evaluate it. (For information on the MS8604A operation, refer to the MS8604A Operation Manual.)

SECTION 5
PERFORMANCE TESTS

This section describes the measuring instruments needed for performance tests, setup, and procedures using the MG0301C π/4 DQPSK Modulation Unit and the MG0303B Burst Function Unit in combination with the MG3670 series • MG3660A Digital Modulation Signal Generator. These performance tests are performed to check if the main performance parameters of the MG0301C and the MG0303B satisfy standard levels.

TABLE OF CONTENTS

5.1 Performance Tests Requirement 5-3

5.2 Instruments Required for Performance Tests 5-3

5.3 Performance Tests 5-4

5.3.1 I/Q signal modulation accuracy 5-4

5.3.2 RF output modulation accuracy 5-6

5.3.3 Modulation pattern 5-8

5.3.4 Burst signal On/Off ratio 5-10

5.3.5 Leakage power of adjacent channel characteristics 5-11

(Blank)

SECTION 5
PERFORMANCE TESTS

5.1 Performance Tests Requirement

Performance tests are performed as preventive maintenance to prevent performance deterioration. Performance tests are required at acceptance inspection, periodic inspection, and post-repair performance verification.

The following are the items that should be tested for verifying the performance of the MG0301C:

- I/Q signal modulation accuracy
- RF output modulation accuracy
- Modulation pattern

The following are the item that should be tested for verifying the performance of the MG0303B:

- Burst signal On/Off ratio

When used in combination with the MG3670 series • MG3660A (main instrument), conduct the following performance test:

- Leakage power of adjacent channel characteristics

Execute performance tests periodically as preventive maintenance for important items. They should be executed at least once or twice a year to check performance. Contact the ANRITSU service department if the MG0301C or MG0303B fails to meet the specifications during performance tests.

5.2 Instruments Required for Performance Tests

The table below lists the measuring instruments required for the performance tests.

Recommended instrument (Anritsu model)	Required performance[†1]	Test items
Digital Mobile Radio Transmitter Tester (MS8604A)	400 kHz to 2.25 GHz[†2]	• I/Q signal modulation accuracy • RF output modulation accuracy
Data Transmission Analyzer (MD6420A)[†3]	42 to 384 kbps	• Modulation pattern
Spectrum Analyzer (MS2602A)	300 kHz to 5 GHz	• Burst signal On/Off ratio

[†1] Only part of the performance that covers the test item measurement range is extracted.

[†2] The frequency upper limit conforms to specifications of the MG3670 series • MG3660A.

[†3] Error rate measuring instrument

5.3 Performance Tests

Before executing the performance tests explained on the following pages, unless otherwise specified, the instrument under test and all the other measuring instruments must be warmed-up for at least 30 minutes so the test is executed under stable conditions. To measure at the highest accuracy, the tests must be performed at room temperature, and ac power-supply voltage fluctuations must be minimized, and vibration and humidity must be kept at a reasonable level.

5.3.1 I/Q signal modulation accuracy

Verify the modulation accuracy of the I/Q signal output.

(1) Test specifications

- Modulation accuracy ..... 1.5 %rms (at 50 Ω, 500 mVrms output)

(2) Test instrument

- Digital Mobile Radio Transmitter Tester MS8604A

  MS8604A options needed for measurement work:

  Option 03: IQ input ..... Used in the analysis of I/Q signals
  Option 11: PDC software ..... Used in the analysis of PDC signals
  Option 12: PHP software ..... Used in the analysis of PHP signals
  Option 13: NADC software ..... Used for the analysis of NADC signals

(3) Setup



(5) Test procedure

Step	Procedure
1	Set the MG3670 series • MG3660A I/Q output level to 50 Ω / 500 mVrms.
2	Set the MG3670 series • MG3660A to the modulation system to be tested.
3	Set the MG3670 series • MG3660A modulation pattern to PN9 pseudorandom pattern.
4	Set the MS8604A so that the modulation system and pattern set in steps 2 and 3 can be received.
5	Using the MS8604A, measure the modulation accuracy and the I/Q signal.

Step	Procedure
	When an MG0303B burst function unit is installed, perform steps 6 to 9.
6	Set the MG3670 series • MG3660A burst function to On.
7	Set the modulation pattern to the communications channel.
8	Set the MS8604A so that the pattern set in step 7 can be received.
9	Using the MS8604A, measure the modulation accuracy and the I/Q signal. (For information on the MS8604A operation, refer to the MS8604A Operation Manual.)

5.3.2 RF output modulation accuracy

Verify the modulation accuracy of the RF modulation signal output.

(1) Test specifications

- Frequency range ..... 300 kHz to 2.25 GHz† (PDC, NADC,PDC_H)
  1 MHz to 2.25 GHz† (PHP)
- Modulation accuracy
  ..... 1.8% rms (at ≦ +5 dBm output level, installed in the MG3670B/3671A)
  2.5% rms (at +5 dBm output level, installed in the MG3660A)

Note: *The 300 to 400 kHz ranges of PDC and NADC and the 1 to 10 MHz range of PHP cannot be measured with the MS8604A.*

†: The frequency upper limit conforms to specifications of the MG3670 series • MG3660A.

(2) Test instrument

- Digital Mobile Radio Transmitter Tester MS8604A

  MS8604A options needed for measurement work:

  Option 11: PDC software ..... Used in the analysis of PDC signals
  Option 12: PHP software ..... Used in the analysis of PHP signals
  Option 13: NADC software ..... Used for the analysis of NADC signals

(3) Setup



(4) Test procedure

Step	Procedure
1	Set the MG3670 series • MG3660A to the frequency to be tested.
2	Set the MG3670 series • MG3660A output level to +5 dBm.
3	Set the MG3670 series • MG3660A to the modulation system to be tested.
4	Set the MG3670 series • MG3660A modulation pattern to PN9 pseudorandom pattern.
5	Set the MS8604A so that the modulation system and pattern set in steps 3 and 4 can be received.
6	Using the MS8604A, measure the modulation accuracy of the RF modulation signal.
	When an MG0303B burst function unit is installed, perform steps 7 to 10
7	Set the MG3670 series • MG3660A burst function to On.

Step	Procedure
8	Set the modulation pattern to the communications channel.
9	Set the MS8604A so that the pattern set in step 8 can be received.
10	Using the MS8604A, Measure the modulation accuracy of the RF modulation signal (For information on the MS8604A operation, refer to the MS8604A Operation Manual.)

5.3.3 Modulation pattern

Verify the modulation pattern.

(1) Test specifications

- PN9 and PN15 pseudorandom pattern ..... Burst function Off
- PN9 and PN15 pseudorandom pattern on slot ..... Burst function Off

(2) Test instrument

- Data Transmission Analyzer MD6420A

  MD6420A unit needed for measurement work:

  MD0626A ..... TTL Interface Unit

(3) Setup



(4) Test procedure

Step	Procedure
1	Set the MG3670 series • MG3660A to the modulation system to be tested.
2	Set the MG3670 series • MG3660A modulation pattern to PN9/PN15 pseudorandom pattern.
3	Connect the MG3670 series • MG3660A data output and data clock to the code error rate measuring instrument. (Connect the data and the clock to the RD (Data) and RT (clock) connectors of the TTL Interface Unit (MD0626A) inserted on the MD6420A rear panel, respectively.)
4	Set the MD6420A receive timing to RT (INV) mode.
5	Set the MD6420A pattern to 2^9-1 (PN9) and $2^{15}-1$ (PN15).
6	Press the MD6420A MEAS key to measure the code error rate.
	When the MG0303B burst function unit is installed, perform steps 7 to 12.
7	Set the MG3670 series • MG3660A burst function to On.
8	Set the modulation pattern to the communications channel.
9	Set TCH (Traffic Channel) to PN9/PN15 pseudorandom pattern.

Step	Procedure
10	Set the Pattern Sync output signal to PN Clock.
11	Set the MD6420A pattern to 2^9-1 (PN9) and $2^{15}-1$ (PN15).
12	Press the MD6420A MEAS key to measure the code error rate.

Note: • *Set the polarity of the MG3670 series • MG3660A data output to positive.*
• *For information on the MD6420A operation, refer to the MD6420A Operation Manual.*

5.3.4 Burst signal On/Off ratio

Verify the On/Off ratio of the burst signal output.

(1) Test specifications

- Frequency range ..... 300 kHz to 2.25 GHz† (PDC, NADC,TFTS, PDC_H)
  1 MHz to 2.25 GHz† (PHP)
- On/Off ratio ..... ≧80 dB: at 5 dBm output, installed in the MG3670B/3671A
  (PDC, NADC, TFTS, PDC_H)
  ≧75 dB: at 5 dBm output, installed in the MG3660A
  (PDC, NADC, TFTS, PDC_H)
  ≧75 dB: at 5 dBm output (PHP)

†: The frequency upper limit conforms to specifications of the MG3670 series • MG3660A.

(2) Test instrument

- Spectrum analyzer MS2602A

(3) Setup



(4) Test procedure

Step	Procedure
1	Set the MG3670 series • MG3660A to the frequency to be tested.
2	Set the MG3670 series • MG3660A output level to +5 dBm.
3	Set the MG3670 series • MG3660A to the modulation system to be tested.
4	Set the MG3670 series • MG3660A burst function to On.
5	Set the MS2602A to the frequency to be tested.
6	Set the MS2602A sweep frequency width to 0 Hz, and observe the output level on and off condition in the time domain.
7	Set the MS2602A parameters to suitable levels, and measure the On and Off ratio. *(For information on the MS2602A operation, refer to the MS2602A Operation Manual.)*

5.3.5 Leakage power of adjacent channel characteristics

Check the leakage power of adjacent channel characteristics as instructed below.

(1) Test specifications

- Frequency range ..... 1 to 2.25 GHz† (PHP)
- Leakage power of adjacent channel ratio
  ..... ≦ −74 dB: MG3670B/3671A, 600 kHz/900 kHz offset, ±96 kHz bandwidth, ≧10 MHz
  ≦ −69 dB: MG3660A, 600 kHz/900 kHz offset, ±96 kHz bandwidth, ≧10 MHz

†: The frequency upper limit conforms to specifications of the MG3670 series • MG3660A.

(2) Test instrument

- Spectrum analyzer MS2602A
  (with leakage power of adjacent channel measurement function)

(3) Setup



(4) Test procedure

Step	Procedure
1	Set the MG3670 series • MG3660A to the frequency to be tested.
2	Set the output level, for example, to −10 dBm.
3	Set the modulation to On and the communications system to PHP.
4	Set the modulation pattern to PN9. For a model with burst function, conduct the test with the burst function set to On.
5	Set the MS2602A to the frequency of Step 1.
6	Set the MS2602A sweep frequency width to about 1 MHz.
7	Set the MS2602A sweep time to 5 s or more.
8	Set other parameters of the MS2602A to optimum levels.
9	Measure the leakage power of adjacent channel ratio using the leakage power of adjacent channel ratio measurement function. (For information on the MS2602A operation, refer to the MS2602A Operation Manual.)

(Blank)

SECTION 6
STORAGE AND TRANSPORTATION

This section describes the long-term storage, repacking and transportation of the MG0301C π/4 DQPSK Modulation Unit and MG0303B Burst Function Unit.

TABLE OF CONTENTS

6.1 Storage Precautions 6-3
6.1.1 Precautions before storage 6-3
6.1.2 Recommended storage precautions 6-3
6.2 Repacking and Transportation 6-3
6.2.1 Repacking 6-3
6.2.2 Transportation 6-3

(Blank)

SECTION 6
STORAGE AND TRANSPORTATION

6.1 Storage Precautions

This paragraph describes the precautions to take for long-term storage of the MG0301C and MG0303B.

6.1.1 Precautions before storage

Avoid storing the MG0301C and MG0303B where:

1) It may be exposed to direct sunlight or high dust levels.
2) It may be exposed to high humidity.
3) It may be exposed to active gases.
4) It may be exposed to extreme temperatures ($< -40°C$ or $> 70°C$) or high humidity ($\geqq 90\%$).

6.1.2 Recommended storage precautions

The recommended storage conditions are as follows:

- Temperature ..... 0 to 30°C
- Humidity ..... 40% to 80%
- Stable temperature and humidity over 24-hour period

6.2 Repacking and Transportation

The following precautions should be taken if the MG0301C/MG0303B must be returned to Anritsu Corporation for servicing.

6.2.1 Repacking

Use the original packing materials. If the MG0301C/MG0303B is packed in other materials, observe the following packing procedure:

(1) Wrap the MG0301C/MG0303B in a plastic sheet or similar material.

(2) Use a cardboard, wooden box, or aluminum case which allows shock-absorbent material to be inserted on all sides of the equipment.

(3) Use enough shock-absorbent material to protect the MG0301C/MG0303B from shock during transportation and to prevent it from moving in the container.

(4) Secure the container with packing straps, adhesive tape or bands.

6.2.2 Transportation

Do not subject the MG0301C/MG0303B to severe vibration during transport. It should be transported under the storage conditions recommended.

(Blank)

MG0301C

π/4 DQPSK Modulation Unit

Operation Manual
(GPIB Remote Control)

(Blank)

TABLE OF CONTENTS

1 GENERAL 1-1

2 MG0301C DEVICE MESSAGE LIST 2-1

2.1 How to Read the MG0301C Device Message List 2-1
2.2 MG0301C Device Message List 2-2

3 DETAILED DESCRIPTION OF COMMANDS 3-1

4 SAMPLE PROGRAMS 4-1

4.1 Generating π/4DQPSK Modulation Signal 4-1
4.2 Setting the Internal Modulation Data 4-2

(Blank)

1. GENERAL

The MG0301C π/4DQPSK Modulation Unit is one of the units used with the MG3670 series • MG3660A Digital Modulation Signal Generator.

This GPIB remote control part provides the MG0301C device message list, its detailed descriptions , and some sample programs with those commands specific to the MG0301C.

For other description of GPIB, refer to the GPIB Remote Control part in the MG3670 series • MG3660A Digital Modulation Signal Generator Operation Manual.

(Blank)

2. MG0301C DEVICE MESSAGE LIST

The tables on the following pages list the command messages, query messages, and response messages specific to the MG0301C π/4DQPSK Modulation Unit.

2.1 How to Read the MG0301C Device Message List

(1) Command Messages (Command Msg)/Query Message (Query Msg)

(a)	Upper-case:	Reserved word
(b)	Number:	Reserved word (Number code)
(c)	Lower-case argument	
	n (Integral number):	Numeric data (NR1 format)
	h (hexadecimal number):	Numeric data (hexadecimal data)
	s:	Character string enclosed by double quotation marks (" ") or single quotation marks (' ')

(2) Response message (Response Msg)

(a)	Upper-case:	Reserved word
(b)	Number:	Reserved word (Number code)
(c)	Lower-case argument	
	n (Integral number):	Numeric data (NR1 format)
	h (hexadecimal number):	Numeric data (hexadecimal data)

Note: • *If the header is set to Off, then the response message header and the numeric data suffix code are not transferred. (Initial setting: Header Off)*

- ␣ *means a space of one character.*
- Ø *indicates a zero.*

2.2 MG0301C Device Message List

(1) Modulation

Measurement paramete		Command Msg	Query Msg	Response Msg
Brief Function	Control Item			
Sets I,Q signal source	Modulation Mode Source			
	I, Q Int	MODE␣INT	MODE?	MODE␣INT
	I, Q Ext	MODE␣EXT	MODE?	MODE␣EXT
Sets nyquist filter type	Nyquist Filter Type			
	Root Nyquist	NYQ␣R	NYQ?	NYQ␣R
	Nyquist	NYQ␣N	NYQ?	NYQ␣N
Differential phase encoding	Differential Phase Encoding			
	Normal	DPE␣NORM	DPE?	DPE␣NORM
	Invers	DPE␣INVS	DPE?	DPE␣INVS
Sets internal modulation data (BURST OFF)	Pattern			
	0000	PAT␣0000	PAT?	PAT␣0000
	0001	PAT␣0001	PAT?	PAT␣0001
	0010	PAT␣0010	PAT?	PAT␣0010
	0011	PAT␣0011	PAT?	PAT␣0011
	0100	PAT␣0100	PAT?	PAT␣0100
	0101	PAT␣0101	PAT?	PAT␣0101
	0110	PAT␣0110	PAT?	PAT␣0110
	0111	PAT␣0111	PAT?	PAT␣0111
	1000	PAT␣1000	PAT?	PAT␣1000
	1001	PAT␣1001	PAT?	PAT␣1001
	1010	PAT␣1010	PAT?	PAT␣1010
	1011	PAT␣1011	PAT?	PAT␣1011
	1100	PAT␣1100	PAT?	PAT␣1100
	1101	PAT␣1101	PAT?	PAT␣1101
	1110	PAT␣1110	PAT?	PAT␣1110
	1111	PAT␣1111	PAT?	PAT␣1111
	PN15	PAT␣PN15	PAT?	PAT␣PN15
	PN9	PAT␣PN9	PAT?	PAT␣PN9
Turns Burst function on or off	Burst			
	On	BST␣ON	BST?	BST␣ON
	Off	BST␣OFF	BST?	BST␣OFF
Sets burst trigger source	Burst Trigger			
	Int	BTG␣INT	BTG?	BTG␣INT
	Ext	BTG␣EXT	BTG?	BTG␣EXT
Changes symbol adjust state	Symbol Adjust	SAD	———	———
Sets timing of the burst trigger	Burst Trigger Select			
	Uplink	TGS␣UP	TGS?	TGS␣UP
	Downlink	TGS␣DN	TGS?	TGS␣DN

(2) Internal modulation data

Measurement paramete		Command Msg	Query Msg	Response Msg
Brief Function	Control Item			
Selects communication systems	System			
	PDC	SYS␣PDC	SYS?	SYS␣PDC
	PDC_H	SYS␣PDC_H	SYS?	SYS␣PDC_H
	PHP	SYS␣PHP	SYS?	SYS␣PHP
	NADC	SYS␣NADC	SYS?	SYS␣NADC
	TFTS	SYS␣TFTS	SYS?	SYS␣TFTS
Sets internal modulation data (BURST ON)	Pattern			
	PDC / PDC_H			
	DEVICE	PAT␣DEV	PAT?	PAT␣DEV
	UP TCH	PAT␣UPT	PAT?	PAT␣UPT
	UP TCH ALL	PAT␣UPTA	PAT?	PAT␣UPTA
	UP VOX	PAT␣UPVX	PAT?	PAT␣UPVX
	DOWN TCH	PAT␣DNT	PAT?	PAT␣DNT
	DOWN TCH ALL	PAT␣DNTA	PAT?	PAT␣DNTA
	PHP			
	UP DEVICE	PAT␣UPDV	PAT?	PAT␣UPDV
	DOWN DEVICE	PAT␣DNDV	PAT?	PAT␣DNDV
	UP TCH	PAT␣UPT	PAT?	PAT␣UPT
	UP TCH ALL	PAT␣UPTA	PAT?	PAT␣UPTA
	DOWN TCH	PAT␣DNT	PAT?	PAT␣DNT
	DOWN TCH ALL	PAT␣DNTA	PAT?	PAT␣DNTA
	UP VOX	PAT␣UPVX	PAT?	PAT␣UPVX
	DOWN VOX	PAT␣DNVX	PAT?	PAT␣DNVX
	UP SYNC	PAT␣UPSYNC	PAT?	PAT␣UPSYNC
	DOWN SYNC	PAT␣DNSYNC	PAT?	PAT␣DNSYNC
	NADC			
	DEVICE	PAT␣DEV	PAT?	PAT␣DEV
	UP TCH	PAT␣UPT	PAT?	PAT␣UPT
	UP TCH ALL	PAT␣UPTA	PAT?	PAT␣UPTA
	DOWN TCH	PAT␣DNT	PAT?	PAT␣DNT
	DOWN TCH ALL	PAT␣DNTA	PAT?	PAT␣DNTA
	TFTS			
	DEVICE	PAT␣DEV	PAT?	PAT␣DEV
	UP TCH	PAT␣UPT	PAT?	PAT␣UPT
	UP TCH ALL	PAT␣UPTA	PAT?	PAT␣UPTA
	DOWN TCH	PAT␣DNT	PAT?	PAT␣DNT
	DOWN TCH ALL	PAT␣DNTA	PAT?	PAT␣DNTA
	Memory	PAT␣MEMn	PAT?	PAT␣MEMn

(3) Setting the slot

Measurement paramete		Command Msg	Query Msg	Response Msg
Brief Function	Control Item			
Selects slot number	Select Slot Number	SLOTNO␣n	SLOTNO?	SLOTNO␣n
Sets the slot	Modify Slot			
	PDC / PDC_H			
	DEVICE:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	UP TCH:			
	UP TCH	SLOT␣UPT	SLOT?	SLOT␣UPT
	VOX	SLOT␣VOX	SLOT?	SLOT␣VOX
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	UP TCH ALL:			
	UP TCH	SLOT␣UPT	SLOT?	SLOT␣UPT
	VOX	SLOT␣VOX	SLOT?	SLOT␣VOX
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	UP VOX:			
	UP TCH	SLOT␣UPT	SLOT?	SLOT␣UPT
	VOX	SLOT␣VOX	SLOT?	SLOT␣VOX
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	DOWN TCH:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	DOWN TCH ALL:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	PHP			
	UP DEVICE:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	DOWN DEVICE:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	UP TCH:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	UP TCH ALL:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	DOWN TCH:			
	DOWN TCH	SLOT␣DNT	SLOT?	SLOT␣DNT
	VOX	SLOT␣VOX	SLOT?	SLOT␣VOX
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF

(Continued)

Measurement paramete		Command Msg	Query Msg	Response Msg
Brief Function	Control Item			
Sets the slot (Continued)	DOWN TCH ALL:			
	DOWN TCH	SLOT␣DNT	SLOT?	SLOT␣DNT
	VOX	SLOT␣VOX	SLOT?	SLOT␣VOX
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	UP VOX:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	DOWN VOX:			
	DOWN TCH	SLOT␣DNT	SLOT?	SLOT␣DNT
	VOX	SLOT␣VOX	SLOT?	SLOT␣VOX
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	UP SYNC:			
	UP TCH	SLOT␣UPT	SLOT?	SLOT␣UPT
	UP SYNC	SLOT␣UPSYNC	SLOT?	SLOT␣UPSYNC
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	DOWN SYNC:			
	DOWN TCH	SLOT␣DNT	SLOT?	SLOT␣DNT
	DOWN SYNC	SLOT␣DNSYNC	SLOT?	SLOT␣DNSYNC
	VOX	SLOT␣VOX	SLOT?	SLOT␣VOX
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	NADC DEVICE:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	UP TCH:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	UP TCH ALL:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	DOWN TCH:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	DOWN TCH ALL:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	TFTS DEVICE:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF

(Continued)

Measurement paramete		Command Msg	Query Msg	Response Msg
Brief Function	Control Item			
Sets the slot (Continued)	UP TCH:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	UP TCH ALL:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	DOWN TCH:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF
	DOWN TCH ALL:			
	On	SLOT␣ON	SLOT?	SLOT␣ON
	Off	SLOT␣OFF	SLOT?	SLOT␣OFF

(4) Setting data of the pattern

Measurement paramete		Command Msg	Query Msg	Response Msg
Brief Function	Control Item			
Sets data of the pattern	Pattern Edit			
	PDC / PDC_H			
	DEVICE:PN			
	PN9	PN␣PN9	PN?	PN␣PN9
	PN15	PN␣PN15	PN?	PN␣PN15
	UP TCH:CC	CC␣h	CC?	CC␣h
	UP TCH:SACCH	SACCHh	SACCH?	SACCH␣h
	UP TCH:SW	SW␣h	SW?	SW␣h
	UP TCH:TCH			
	PN9	TCH␣PN9	TCH?	TCH␣PN9
	PN15	TCH␣PN15	TCH?	TCH␣PN15
	UP TCH:Scramble			
	ON	SCBL␣ON	SCBL?	SCBL␣ON
	OFF	SCBL␣OFF	SCBL?	SCBL␣OFF
	UP TCH:Scramble Code	SCBLC␣h	SCBLC?	SCBLC␣h
	DOWN TCH:CC	CC␣h	CC?	CC␣h
	DOWN TCH:SACCH	SACCH␣h	SACCH?	SACCH␣h
	DOWN TCH:SW	SW␣h	SW?	SW␣h
	DOWN TCH:TCH			
	PN9	TCH␣PN9	TCH?	TCH␣PN9
	PN15	TCH␣PN15	TCH?	TCH␣PN15

(Continued)

Measurement paramete		Command Msg	Query Msg	Response Msg
Brief Function	Control Item			
Sets data of the pattern (Continued)	Pattern Edit			
	DOWN TCH:Scramble			
	ON	SCBL␣ON	SCBL?	SCBL␣ON
	OFF	SCBL␣OFF	SCBL?	SCBL␣OFF
	DOWN TCH:Scramble Code	SCBLC␣h	SCBLC?	SCBLC␣h
	VOX:CC	CC␣h	CC?	CC␣h
	VOX:SACCH	SACCH␣h	SACCH?	SACCH␣h
	VOX:SW	SW␣h	SW?	SW␣h
	VOX:Scramble			
	ON	SCBL␣ON	SCBL?	SCBL␣ON
	OFF	SCBL␣OFF	SCBL?	SCBL␣OFF
	VOX:Scramble Code	SCBLC␣h	SCBLC?	SCBLC␣h
	PHP			
	DEVICE:PN			
	PN9	PN␣PN9	PN?	PN␣PN9
	PN15	PN␣PN15	PN?	PN␣PN15
	TCH:UW	UW␣h	UW?	UW␣h
	TCH:SA	SA␣h	SA?	SA␣h
	TCH:TCH			
	PN9	TCH␣PN9	TCH?	TCH␣PN9
	PN15	TCH␣PN15	TCH?	TCH␣PN15
	TCH:CS-ID Scramble			
	ON	SCBL␣ON	SCBL?	SCBL␣ON
	OFF	SCBL␣OFF	SCBL?	SCBL␣OFF
	TCH:CS-ID Code	SCBLC␣h	SCBLC?	SCBLC␣h
	TCH:Secret Scramble			
	ON	SCRT␣ON	SCRT?	SCRT␣ON
	OFF	SCRT␣OFF	SCRT?	SCRT␣OFF
	TCH:Secret Code	SCRTC␣h	SCRTC?	SCRTC␣h
	VOX:UW	UW␣h	UW?	UW␣h
	VOX:SA	SA␣h	SA?	SA␣h
	VOX:VOX			
	PN9	VOX␣PN9	VOX?	VOX␣PN9
	PN15	VOX␣PN15	VOX?	VOX␣PN15

(Continued)

Measurement paramete		Command Msg	Query Msg	Response Msg
Brief Function	Control Item			
Sets data of the pattern (Continued)	Pattern Edit			
	VOX:CS-ID Scramble			
	ON	SCBL␣ON	SCBL?	SCBL␣ON
	OFF	SCBL␣OFF	SCBL?	SCBL␣OFF
	VOX:CS-ID Code	SCBLC␣h	SCBLC?	SCBLC␣h
	VOX:Secret Scramble			
	ON	SCRT␣ON	SCRT?	SCRT␣ON
	OFF	SCRT␣OFF	SCRT?	SCRT␣OFF
	VOX:Secret Code	SCRTC␣h	SCRTC?	SCRTC␣h
	SYNC:UW	UW␣h	UW?	UW␣h
	SYNC:CI	CI␣h	CI?	CI␣h
	SYNC:CS-ID	CSID␣h	CSID?	CSID␣h
	SYNC:PS-ID	PSID␣h	PSID?	PSID␣h
	SYNC:Idle	IDLE␣h	IDLE?	IDLE␣h
	SYNC:Scramble			
	ON	SCBL␣ON	SCBL?	SCBL␣ON
	OFF	SCBL␣OFF	SCBL?	SCBL␣OFF
	SYNC:Scramble Code	SCBLC␣h	SCBLC?	SCBLC␣h
	NADC			
	DEVICE:PN			
	PN9	PN␣PN9	PN?	PN␣PN9
	PN15	PN␣PN15	PN?	PN␣PN15
	UP TCH:CDVCC	CDVCC␣h	CDVCC?	CDVCC␣h
	UP TCH:SACCH	SACCH␣h	SACCH?	SACCH␣h
	UP TCH:SYNC	SYNC␣h	SYNC?	SYNC␣h
	UP TCH:DATA			
	PN9	DATA␣PN9	DATA?	DATA␣PN9
	PN15	DATA␣PN15	DATA?	DATA␣PN15
	DOWN TCH:CDVCC	CDVCC␣h	CDVCC?	CDVCC␣h
	DOWN TCH:SACCH	SACCH␣h	SACCH?	SACCH␣h
	DOWN TCH:SYNC	SYNC␣h	SYNC?	SYNC␣h
	DOWN TCH:DATA			
	PN9	DATA␣PN9	DATA?	DATA␣PN9
	PN15	DATA␣PN15	DATA?	DATA␣PN15

(Continued)

Measurement paramete		Command Msg	Query Msg	Response Msg
Brief Function	Control Item			
Sets data of the pattern (Continued)	Pattern Edit			
	TFTS			
	DEVICE:PN			
	PN9	PN␣PN9	PN?	PN␣PN9
	PN15	PN␣PN15	PN?	PN␣PN15
	TCH:S	S␣h	S?	S␣h
	TCH:DATA			
	PN9	DATA␣PN9	DATA?	DATA␣PN9
	PN15	DATA␣PN15	DATA?	DATA␣PN15

(5) Save

Measurement paramete		Command Msg	Query Msg	Response Msg
Brief Function	Control Item			
Saves burst internal modulation data	Burst Pattern Memory Save	BSAV␣n[,s]†	———	———

† It is possible to omit 's'(Title).

(Blank)

3. DETAILED DESCRIPTION OF COMMANDS

This section describes in detail the device messages for MG0301C π/4DQPSK Modulation Unit. The device messages are listed in alphabetical.

TABLE OF CONTENTS

BSAV 3-2
BST 3-2
BTG 3-3
CC 3-4
CDVCC 3-4
CI 3-5
CSID 3-5
DATA 3-6
DPE 3-6
IDLE 3-7
MODE 3-8
NYQ 3-9
PAT 3-10
PAT 3-11
PAT 3-11
PN 3-12
PSID 3-12
S 3-13
SA 3-13
SACCH 3-14
SAD 3-15
SCBL 3-15
SCBLC 3-16
SCRT 3-16
SCRTC 3-17
SLOT 3-18
SLOTNO 3-20
SW 3-20
SYNC 3-21
SYS 3-21
TCH 3-22
TGS 3-22
UW 3-23
VOX 3-24

B

BSAV Burst Pattern Memory Save

■ Function

Saves the burst internal modulation data to burst pattern memory.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
BSAV	BSAV␣a[,b]	———	———

■ Value of a

Ø to 99

■ Value of b

Character string whithin 8 characters enclosed by double quotation marks or single quotation marks.
Saves the title which is sets currently if b is omitted.
Saves the first eight characters of b if b is over eight characters.

■ Suffix code

None

■ Example

BSAV␣5, "MG3670B"

BST Burst On/Off

■ Function

Turns the Burst function on or off.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
BST	BST␣a	BST?	BST␣a

■ Value of a

ON: On
OFF: Off

■ Suffix code

None

■ Initial setting

OFF

■ Example

BST␣ON

BTG Burst Trigger Source

■ Function

Sets the burst trigger source to either internal (Int) or external (Ext). (When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
BTG	BTG␣a	BTG?	BTG␣a

■ Value of a

INT: Internal burst trigger
EXT: External burst trigger

■ Suffix code

None

■ Initial setting

INT

■ Example

BTG␣EXT

C

CC Color Code

■ Function

Sets the CC data of VOX/UP TCH/DOWN TCH slot in the PDC/PDC_H.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
CC	CC␣a	CC?	CC␣a

■ Value of a #HØØ to #HFF (Hexadecimal number)

■ Suffix code None

■ Initial setting #HØØ

■ Example CC␣#H3F

CDVCC Coded Digital Verification Color Code

■ Function

Sets the CDVCC data of UP TCH/DOWN TCH slot in the NADC.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
CDVCC	CDVCC␣a	CDVCC?	CDVCC␣a

■ Value of a #HØØØ to #HFFF (Hexadecimal number)

■ Suffix code None

■ Initial setting #HØØØ

■ Example CDVCC␣#HAAA

CI Channel Identifier

■ Function Sets the CI data of SYNC slot in the PHP system.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
CI	CI␣a	CI?	CI␣a

■ Value of a #HØ to #HF (Hexadecimal number)
■ Suffix code None
■ Initial setting #H9
■ Example CI␣#HF

CSID CS Identification Code

■ Function Sets the CS-ID data of SYNC slot in the PHP system.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
CSID	CSID␣a	CSID?	CSID␣a

■ Value of a #HØØØØØØØØØØØ to #H3FFFFFFFFFF (Hexadecimal number)
■ Suffix code None
■ Initial setting #H2Ø2ØØØ2ØØØ1
■ Example CSID␣#H2Ø2ØØØ2ØØØ3

D

DATA Data

■ Function

Sets parameter data (DATA) for UP-TCH/DOWN-TCH slots of the NADC system or TCH of the TFTS system when the burst function unit is installed.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
DATA	DATA␣a	DATA?	DATA␣a

■ Value of a PN9, PN15

■ Suffix code None

■ Initial setting PN9

■ Example DATA␣PN15

DPE Differential Phase Encoding

■ Function

Sets the differential phase encoding specifications for π/4DQPSK modulation when a π/4DQPSK modulation system is selected.

Header	Program command	Query	Response
DATA	DATA␣a	DATA?	DATA␣a

■ Value of a NORM : Normal
INVS : Inverse (inverted differential phase encoding)

■ Suffix code None

■ Initial setting NORM

■ Example DPE␣INVS

IDLE Idle Bit

■ Function Sets the Idle data of SYNC slot in the PHP system.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
IDLE	IDLE␣a	IDLE?	IDLE␣a

■ Value of a #H000000000 to #H3FFFFFFFF (Hexadecimal number)

■ Suffix code None

■ Initial setting #H000000000

■ Example IDLE␣#H3AAAAAAAA

MODE Modulation Mode Source

■ Function Sets the I,Q signals source to either internal (Int) or external (Ext).

Header	Program command	Query	Response
MODE	MODE␣a	MODE?	MODE␣a

■ Value of a
INT: Internal I,Q signals
EXT: External I,Q signals

■ Suffix code None

■ Initial setting INT

■ Example MODE␣EXT

NYQ Nyquist Filter Type

■ Function Sets the nyquist filter type to either Root Nyquist or Nyquist .

Header	Program command	Query	Response
NYQ	NYQ␣a	NYQ?	NYQ␣a

■ Value of a
R: Root Nyquist
N: Nyquist

■ Suffix code None

■ Initial setting R

■ Example NYQ␣N

PAT Pattern

■ Function

Sets the internal modulation data pattern when the burst function turns on. (When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
PAT	PAT␣a	PAT?	PAT␣a

■ Value of a

When system is PDC/PDC_H

DEV:	DEVICE
UPT:	UP TCH
UPTA:	UP TCH ALL
UPVX:	UP VOX
DNT:	DOWN TCH
DNTA:	DOWN TCH ALL

When system is PHP

UPDV:	UP DEVICE
DNDV:	DOWN DEVICE
UPT:	UP TCH
UPTA:	UP TCH ALL
DNT:	DOWN TCH
DNTA:	DOWN TCH ALL
UPVX:	UP VOX
DNVX:	DOWN VOX
UPSYNC:	UP SYNC
DNSYNC:	DOWN SYNC

When system is NADC

DEV:	DEVICE
UPT:	UP TCH
UPTA:	UP TCH ALL
DNT:	DOWN TCH
DNTA:	DOWN TCH ALL

When system is TFTS

DEV:	DEVICE
UPT:	UP TCH
UPTA:	UP TCH ALL
DNT:	DOWN TCH
DNTA:	DOWN TCH ALL

■ Suffix code None

■ Initial setting UPDV (When system is PHP), DEV (When system is PDC, NADC)

■ Example PAT␣UPT

PAT Pattern

■ Function Sets the internal modulation data pattern when the burst function turns off.

Header	Program command	Query	Response
PAT	PAT␣a	PAT?	PAT␣a

■ Value of a ØØØØ to 1111 (optional 4 bits), PN9, PN15
■ Suffix code None
■ Initial setting PN9
■ Example PAT␣PN15

PAT Pattern in "Memory"

■ Function Chooses the burst internal modulation data from 100 patterns in the burst pattern memory.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
PAT	PAT␣MEMa	PAT?	PAT␣MEMa

■ Value of a ØØ to 99
■ Suffix code None
■ Example PAT␣MEM3

PN Pseudo random

■ Function

Sets the PN data of DEVICE slot.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
PN	PN␣a	PN?	PN␣a

■ Value of a PN9, PN15

■ Suffix code None

■ Initial setting PN9

■ Example PN␣PN15

PSID PS Identification Code

■ Function

Sets the PS-ID data of SYNC slot in the PHP system.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
PSID	PSID␣a	PSID?	PSID␣a

■ Value of a #H00000000 to #HFFFFFFFF (Hexadecimal number)

■ Suffix code None

■ Initial setting #H00000001

■ Example PSID␣#H00000003

S Sync Word

■ Function Sets S data for the TCH slot of TFTS system when the burst function unit is installed.

Header	Program command	Query	Response
S	S␣a	S?	S␣a

■ Value of a #H000 to #H7FF(Hexadecimal number)
■ Suffix code None
■ Initial setting #H414
■ Example SYNC␣#H7FF

SA SACCH Slow Associated Control Channel

■ Function Sets the SA data of VOX/TCH slot in the PHP system.
(When the burst function unit is supported,this function is available)

Header	Program command	Query	Response
SA	SA␣a	SA?	SA␣a

■ Value of a #H0000 to #HFFFF (Hexadecimal number)
■ Suffix code None
■ Initial setting #H8000
■ Example SA␣#HFFFF

SACCH Slow Associated Control Channel

■ Function

Sets the SACCH data of UP TCH/DOWN TCH slot in the PDC/PDC_H/NADC system and VOX slot in the PDC system.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
SACCH	SACCH␣a	SACCH?	SACCH␣a

■ Value of a

When system is PDC/PDC_H

Slot	Range of data
VOX, UP TCH	#HØØØØ to 7FFF
DOWN TCH	#HØØØØØØ to 1FFFFF

When system is NADC

#HØØØ to #HFFF

■ Suffix code

None

■ Initial setting

Depends on the system and slot.

When system is PDC/PDC_H

Slot	Initial data
VOX	#HØØØØ
UP TCH	#HØØØØ
DOWN TCH	#HØØØØØØ

When system is NADC

#HØØØ

■ Example

SACCH␣#H7AAA

SAD Symbol Adjust

■ Function Changes the synchronous state of symbol clock.

Header	Program command	Query	Response
SAD	SAD	———	———

■ Suffix code None

■ Example SAD

SCBL Scramble On/Off, CS-ID Scramble On/Off

■ Function Turns on or off the scramble function of VOX/UP TCH/DOWN TCH slot in the PDC/PDC_H. Sets On/Off for the CS-ID scramble function of the VOX/TCH slot and the scramble function of the SYNC slot of the PHP system.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
SCBL	SCBL␣a	SCBL?	SCBL␣a

■ Value of a ON: On
OFF: Off

■ Suffix code None

■ Initial setting ON

■ Example SCBL␣OFF

SCBLC Scramble Code, CS-ID Scramble Code

■ Function

Sets the scramble code of VOX/UP TCH/DOWN TCH slot in the PDC/PDC_H.
Sets On/Off for the CS-ID scramble function of the VOX/TCH slot and the scramble function of the SYNC slot of the PHP system.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
SCBLC	SCBLC␣a	SCBLC?	SCBLC␣a

■ Value of a

PDC/PDC_H system: #HØØØ to #H1FF (Hexadecimal number)
PHP system: #HØØØ to #H3FF (Hexadecimal number)

■ Suffix code

None

■ Initial setting

PDC/PDC_H system: #HØØØ
PHP system: #H2ØØ

■ Example

PDC system: SCBLC␣#H1FF
PHP system: SCBLC␣#H3FF

SCRT Secret Scramble On/Off

■ Function

Turns on or off the Secret (Encryption) scramble function of VOX/TCH slot in the PHP.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
SCRT	SCRT␣a	SCRT?	SCRT␣a

■ Value of a

ON: On
OFF: Off

■ Suffix code

None

■ Initial setting

ON

■ Example

SCRT␣OFF

SCRTC Secret Scramble Code

■ Function Sets the Secret Scramble (Encryption Key) code VOX/TCH slot in the PHP system. (When the burst function unit is supported,this function is available)

Header	Program command	Query	Response
SCRTC	SCRTC␣a	SCRTC?	SCRTC␣a

■ Value of a #HØØØØ to #HFFFF (Hexadecimal number)

■ Suffix code None

■ Initial setting #HØØØØ

■ Example SCRTC␣#HFFFF

SLOT Slot

■ Function

Modfies the slot contents of the internal modulation data.
(When the burst function unit is supported,this function is available)

Header	Program command	Query	Response
SLOT	SLOT␣a	SLOT?	SLOT␣a

■ Value of a

PDC/PDC_H system ————————
DEVICE:
- On SLOT␣ON
- Off SLOT␣OFF

UP TCH:
- UP TCH SLOT␣UPT
- VOX SLOT␣VOX
- Off SLOT␣OFF

UP TCH ALL:
- UP TCH SLOT␣UPT
- VOX SLOT␣VOX
- Off SLOT␣OFF

UP VOX:
- UP TCH SLOT␣UPT
- VOX SLOT␣VOX
- Off SLOT␣OFF

DOWN TCH:
- On SLOT␣ON
- Off SLOT␣OFF

DOWN TCH ALL:
- On SLOT␣ON
- Off SLOT␣OFF

PHP system ————————
UP DEVICE
- On SLOT␣ON
- Off SLOT␣OFF

DOWN DEVICE
- On SLOT␣ON
- Off SLOT␣OFF

UP TCH:
- On SLOT␣ON
- Off SLOT␣OFF

UP TCH ALL:
- On SLOT␣ON
- Off SLOT␣OFF

DOWN TCH:
- DOWN TCH SLOT␣DNT
- VOX SLOT␣VOX
- Off SLOT␣OFF

DOWN TCH ALL:
- DOWN TCH SLOT␣DNT
- VOX SLOT␣VOX
- Off SLOT␣OFF

■ Value of a (cont.)

UP VOX:	
On	SLOT␣ON
Off	SLOT␣OFF
DOWN VOX:	
DOWN TCH	SLOT␣DNT
VOX	SLOT␣VOX
Off	SLOT␣OFF
UP SYNC:	
UP TCH	SLOT␣UPT
UP SYNC	SLOT␣UPSYNC
Off	SLOT␣OFF
DOWN SYNC:	
DOWN TCH	SLOT␣DNT
DOWN SYNC	SLOT␣DNSYNC
VOX	SLOT␣VOX
Off	SLOT␣OFF

NADC system

DEVICE:	
On	SLOT␣ON
Off	SLOT␣OFF
UP TCH:	
On	SLOT␣ON
Off	SLOT␣OFF
UP TCH ALL:	
On	SLOT␣ON
Off	SLOT␣OFF
DOWN TCH:	
On	SLOT␣ON
Off	SLOT␣OFF
DOWN TCH ALL:	
On	SLOT␣ON
Off	SLOT␣OFF

TFTS system

DEVICE:	
On	SLOT␣ON
Off	SLOT␣OFF
UP TCH:	
On	SLOT␣ON
Off	SLOT␣OFF
UP TCH ALL:	
On	SLOT␣ON
Off	SLOT␣OFF
DOWN TCH:	
On	SLOT␣ON
Off	SLOT␣OFF
DOWN TCH ALL:	
On	SLOT␣ON
Off	SLOT␣OFF

■ Suffix code None

■ Example SLOT␣OFF

SLOTNO Slot Number

■ Function

Selects the slot number in the pattern.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
SLOTNO	SLOTNO␣a	SLOTNO?	SLOTNO␣a

■ Value of a

The slot number range depends on the system.

System	Range of slot number
PDC	Ø to 2
PDC_H	Ø to 5
PHP	1 to 4
NADC	Ø to 2
TFTS	Ø to 16

■ Suffix code

None

■ Initial setting

1 for the PHP system, and 0 for other systems

■ Example

SLOTNO␣1

SW Sync Word

■ Function

Sets the SW data of VOX/UP TCH/DOWN TCH in the PDC/PDC_H.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
SW	SW␣a	SW?	SW␣a

■ Value of a

#HØØØØØ to #HFFFFF (Hexadecimal number)

■ Suffix code

None

■ Initial setting

PDC system	Uplink	Downlink
Slot Ø	#H785B4	#H87A4B
Slot 1	#H62DC9	#H9D236
Slot 2	#H7E28A	#H81D75

PDC_H system	Uplink	Downlink
Slot Ø	#H785B4	#H87A4B
Slot 1	#H62DC9	#H9D236
Slot 2	#H7E28A	#H81D75
Slot 3	#H56B15	#HA94EA
Slot 4	#HAE9B3	#H5164C
Slot 5	#HB2621	#H4D9DE

■ Example

SW␣#HFFFFF

SYNC Sync Word

■ Function Sets the SYNC data of UP TCH/DOWN TCH in the NADC.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
SYNC	SYNC␣a	SYNC?	SYNC␣a

■ Value of a #HØØØØØØØ to #HFFFFFFF (Hexadecimal number)

■ Suffix code None

■ Initial setting Slot Ø #HA91DE4A
Slot 1 #HA9D127A
Slot 2 #HC7E3COC

■ Example SYNC␣#HFFFFFFF

SYS System

■ Function Selects the communication systems.

Header	Program command	Query	Response
SYS	SYS␣a	SYS?	SYS␣a

■ Value of a PDC, PDC_H, PHP, NADC, TFTS

■ Suffix code None

■ Initial setting PDC

■ Example SYS␣PHP

TCH Traffic Channel

■ Function

Sets the TCH data of UP TCH/DOWN TCH slot in the PDC system and TCH slot in the PHP/PDC_H system.
(When the burst function unit is supported,this function is available)

Header	Program command	Query	Response
TCH	TCH␣a	TCH?	TCH␣a

■ Value of a PN9, PN15

■ Suffix code None

■ Initial setting PN9

■ Example TCH␣PN15

TGS Burst Trigger Select

■ Function

Selects the timing of the burst trigger in the PHP sytem.
(When the burst function unit is supported,this function is available)

Header	Program command	Query	Response
TGS	TGS␣a	TGS?	TGS␣a

■ Value of a UP: Uplink
DN: Downlink

■ Suffix code None

■ Initial setting DN

■ Example TGS␣DN

UW Unique Word

■ Function

Sets the UW data of VOX/TCH/SYNC slot in the PHP sytem.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
UW	UW␣a	UW?	UW␣a

■ Value of a

VOX/TCH slot: #H0000 to #HFFFF (Hexadecimal number)
SYNC slot: #H00000000 to #HFFFFFFFF (Hexadecimal number)

■ Suffix code

None

■ Initial setting

VOX/TCH slot:	Uplink:	#HE149
	Downlink:	#H3D4C
SYNC slot:	Uplink:	#H6B899AF0
	Downlink:	#H50EF2993

■ Example

UW␣#HFFFF

VOX Voice Operated Transmission

■ Function Sets the VOX data of VOX slot in the PHP system.
(When the burst function unit is supported, this function is available)

Header	Program command	Query	Response
VOX	VOX␣a	VOX?	VOX␣a

■ Value of a PN9, PN15
■ Suffix code None
■ Initial setting PN9
■ Example VOX␣PN15

4. SAMPLE PROGRAMS

This section describes some sample programs with the common commands and the program commands, queries, and response messages specific to the MG0301C.

4.1 Generating π/4DQPSK Modulation Signal

< Example 1 > Sets the frequency to 1.5 GHz, output level to 0 dBm and communication system to NADC.

```
10  '------------------------------
20  ' MG3670B GPIB SAMPLE PROGRAM
30  ' OUTPUT π/4 DQPSK MODULATION
40  '------------------------------
50  ISET IFC ..... Initializes the interface function
60  ISET REN ..... Sets remote enable to TRUE
70  CMD DELIM=0 ..... Selects CR + LF as the delimiter
80  LET DSG=1 ..... Assigns MG3670 series • MG3660A address to variable DSG
90  PRINT @DSG;"PRE" ..... Initializes MG3670 series • MG3660A
100 SRQ ON ..... Permits the receipt of SRQ
110 PRINT @DSG;"*CLS" ..... Clears Status Byte Register
120 PRINT @DSG;"*SRE 4" ..... Masks bits other than SRE bit 2
130 PRINT @DSG;"ESE2 4" ..... Masks bits other than ESE2 bit 2
140 PRINT @DSG;"MOD ON" ..... Turns modulation on
150 PRINT @DSG;"MODE INT" ..... Sets the I,Q signals source to internal input
160 PRINT @DSG;"SYS NADC" ..... Sets the communication system to NADC
170 PRINT @DSG;"BST ON" ..... Turns the burst function on
180 PRINT @DSG;"PAT UPT" ..... Sets the standard internal modulation data to UP TCH
190 PRINT @DSG;"FREQ 1.5GHZ" ..... Sets the frequency to 1.5 GHz
200 PRINT @DSG;"OLVL 0DBM" ..... Sets the output Level to 0 dBm
210 POLL DSG,N ..... Performs serial polling
220 IF N<>68 THEN GOTO 210 ..... Exit from loop when STB ESB (bit 2) is 1
230 END
```

Lines 140 and 150 turn the modulation on and sets the I,Q signals source to internal input.
Lines 160 to 180 set the communication system to NADC, turns the burst function on,and sets the standard internal modulation data to Uplink traffic channel.
Lines 190 and 200 set the frequency and output level.
Lines 210 and 220 check that setting parameter has completed.

4.2 Setting the Internal Modulation Data

<Example 2> Sets the internal modulation data in the PDC system.

```
10  '------------------------------
20  ' MG3670B GPIB SAMPLE PROGRAM
30  ' PATTERN EDIT (PDC)
40  '------------------------------
50  ISET IFC
60  ISET REN
70  CMD DELIM=0
80  LET DSG=1
90  PRINT @DSG;"PRE"
140 PRINT @DSG;"MOD ON"
150 PRINT @DSG;"MODE INT"
160 PRINT @DSG;"SYS PDC" ..... Sets the communication system to PDC
170 PRINT @DSG;"BST ON" ..... Turns the burst function on
180 PRINT @DSG;"PAT UPT" ..... Sets the standard internal modulation data to UP TCH
190 PRINT @DSG;"SLOTNO 1" ..... Sets the slot number to 1
200 PRINT @DSG;"SLOT UPT" ..... Sets the slot 1 to UP TCH
210 PRINT @DSG;"TCH PN15" ..... Sets the TCH data of slot 1 to PN15
220 PRINT @DSG;"CC #HFF" ..... Sets the CC data of slot 1 to FF (Hexadecimal number)
230 END
```

Lines 160 to 180 set the communication system to PDC, turns burst function on, and sets the standard internal modulation data to UP TCH.

Line 190 sets the slot number to 1.
Line 200 sets the slot 1 to UPTCH.
Lines 210 and 220 set the TCH data of slot 1 to PN15, and the CC data of slot 1 to FF(Hexadecimal number).

Anritsu Service and Sales Offices

America

Anritsu Wiltron Company
685 Jarvis Drive, Morgan Hill, CA
95037-2809, U.S.A
Phone: 408-776-8300
Fax: 408-776-1744

New Jersey Office
10 Kingsbridge Road Fairfield, NJ
07004, U.S.A
Phone: 201-227-8999
Fax: 201-575-0092

Anritsu Wiltron Eletronica Ltda.
Praia de Botafago 440, Sala 2401
CEP 22250-040, Rio de Janeiro, RJ,
Brazil
Phone: 021-286-9141
Fax: 021-537-1456

Anritsu Wiltron Instruments Ltd.
Unit 102, 215 Stafford Road Nepean,
Ontario K2H 9C1, Canada
Phone: 613-828-4090
Fax: 613-828-5400

Electronica 2000, S.A. de C.V.
Mexico, Mexico
Phone 05-662-8800/9989

Electronic Engineering S.A.
San Jos , Costa Rica
Phone: 2258793/2533759

HDM Elquitecnica Cia. Ltda.
Quito, Ecuador
Phone: 02-464587

Iota S.A.
Buenos Aires, Argentina
Phone: 01-432-8522/8459

Parker S.A.
Santiago, Chile
Phone: 02-231-9976/7147

Radiocom S.A.
Bogota, Colombia
Phone: 01-218-2054

Radiocomunicaciones cruz C.A.
Caracas, Venezuela
Phone: 02-7932322

Suministros Industriales, S.A.
Panama City, Panama
Phone: 64-2605, 69-2738

Vernal S.A.
Montevideo, Uruguay
Phone: 02-920171/920301

Europe

Anritsu Wiltron AB
Box 247, Jägerhorns väg 19, S-127
25 Skärholmen, Sweden
Phone: 08-7405840
Fax: 08-7404800

Anritsu Wiltron GmbH
Grafenberger Allee 54-56, D-40237 D
sseldofr 1, Germany
Phone: 0211-679760
Fax: 0211-683353

Anritsu Wiltron Ltd.
Capability Green, Luton, Bedfordshire
LU1 3LU, United Kingdom
Phone: 1582-418853
Fax: 1582-31303

Anritsu Wiltron S.A.
9, avenue du Québec ZAC de
Courtaboeuf 91951 LES ULIS
CEDEX, France
Phone: 01-64 46 65 46
Fax: 01-64 46 10 65

Anritsu Wiltron S.p.A.
Via Elio Vittorini, N.129, 00144 Roma
Eur, Italy
Phone: 06-5022666
Fax: 06-5022425

Anritsu Wiltron S.p.A. Milano Office
20041 Agrate Brianza (MI), C.D.
Colleoni, Via Paracelso 14, Italy
Phone: 039-639411
Fax: 039-639419

C.N. Rood B.V.
Rijswijk, Netherlands
Phone: 0-70-399-6360

C.N. Rood S.A./N.V.
Zellik, Belgium
Phone: 02-466-8199

Elsinco Bratislava s. r. o.
Bratislava, Slovakia
Phone: 0222-8121751

Elsinco Budapest KFT
Budapest, Hungary
Phone: 01-112-4854

Elsinco GmbH
Wien, Austria
Phone: 0222-8121751

Elsinco Polska Sp.z.o.o.
Warazawa, Poland
Phone: 022-396979

Elsinco Praha s. r. o.
Praha, Czecho
Phone: 02-4702 ex 451, 453

Elsinco Sofia
Sofia, Bulgaria
Phone: 02-581-698

G'Amundason H.F.
Reykjavik, Iceland
Phone: 01-687820

GMP S.A.
Lausanne, Switzerland
Phone: 021-6348181

Instrutek Periferi A/S
Horsens, Denmark
Phone: 75-611100

Into OY
Helsinki, Finland
Phone: 0-755-7711

Kostas Karayannis S.A.
Athens, Greece
Phone: 01-323-0303/7731

Omnitecnica
Amadora, Portugal
Phone: 01-4715517

Teleinstrument AS
Asker, Norway
Phone: 66-901190

Unitronics, S.A.
Madrid, Spain
Phone: 91-542 52 04

Wien Schall GesmbH
Wien, Austria
Phone: 1-81155-140

Asia, Pacific and Africa

Alcatel Australia Ltd.
Sourth Melbourne, Australia
Phone: 03-694-6666
Alcatel Papua New Guinea Ltd.
Port Moresby, Papua New Guinea
Phone: 675-256933

Anritsu Wiltron (Singapore) Pte Ltd.
3 Shenton Way, #24-03, Singapore 106
Phone: 2265206
Fax: 2265207

Anritsu Wiltron Company Limited
Suite 812, 8/F., Chinachem Golden Plaza, 77 Mody Road, Tsim Sha Tsui East Kowloon,
Hong Kong
Phone: 2301-4980
Fax: 2301-3545

Associated Electric Trading Corp.
Lahore, Pakistan
Phone: 042-722-1716/7857

Beijing Liaison Office
Room No. 416, Beijing Fourtune Building 5 Dong San Huan Bei-lu, Chaoyang-qu Beijing 100004, China
Phone: 861-501-7551, 7552
Fax: 861-501-7553

Cha wei Electric Trading Co., Ltd.
Taipei, Taiwan
Phone: 02-561-2211

Chris Radiovision Ltd.
Nicosia, Cyprus
Phone: 02-466121

Etecsa CC
Midrand, South Africa
Phone: 11-315-1366

Giza Systems Engineering Co.
Cairo, Egypt
Phone: 02-3490140

Han-Il Commerce & Company
Seoul, Korea
Phone: 02-783-6391

Infotechs Ltd.
Colombo, Sri Lanka
Phone: 01-580088/500817

Inter Mühendislik Danismanlik ve Ticaret A.S.
Istanbul, Turkey
Phone: 216-349 9400

Meera Agencies (P) Ltd.
New Delhi, India
Phone: 685-3228/3959

Mercantile Information Telecommunication Technology Est.
Abu Dhabi, U.A.E.
Phone: 2-768909

National Projects and Technology Co. Llc
Wadi Kabir, Sultante of Oman
Phone: 791704

New Delhi Liasison Office
Room No. 508, Prakash Deep 7, Tolstoy Marg, New Delhi-110001, India
Phone: 011-3319133
Fax: 011-3713948

O'Connor's Engineering and Trading (Malaysia) Bhd
Selangor, Malaysia
Phone: 03-757-2828

O'Connor's Singapore Pte Ltd.
Singapore
Phone: 473-7944

Schmidt Telecom
Hong Kong
Phone: 507-0222

Scollay Holding Ltd.
Wellington, New Zealand
Phone: 04-4-722-961

P & P Telecom Co., Ltd.
Bangkok, Thailand
Phone: 02-271-2397/0057

P.T. Subur Sakti Putera
Jakarta, Indonesia
Phone: 021-3858361

Rajab & Silsilah & Co.
Jeddah, Saudi Arabia
Phone: 2-6610006

Salritsu International Trading Corporation
Metro Manila, Philippines
Phone: 632-8150946/8938998

Uto Trading Company
Seoul, Korea
Phone: 02-765-1800/1801

Japan

Head Office
5-10-27, Minamiazabu, Minato-ku, Tokyo 106
Phone: 03-3446-1111
Fax: 03-3442-0235

Atsugi Factory
1800, Onna, Atsugi-si, Kanagawa 243
Phone: 0462-23-1111
Fax: 0462-25-8379

Koriyama Factory
301, Dooba, Aza, Koriyama-shi, Fukushima 963
Phone: 0249-56-2112
Fax: 0249-56-2299

Osaka (Anritsu Technics)
1-10-31, Mikunihonmachi, Yodogawa-ku, Osaka 532
Phone: 06-391-0697
Fax: 06-391-1748

Anritsu

ANRITSU CORPORATION
5-10-27, Minamiazabu, Minato-ku, Tokyo, 106 Japan
PHONE. 03-3446-1111
TELEX J 34372 ANRITU

www.manualsplus.com
1030510